
MODEL **3566**

Digital AC m Ω Meter

Instruction Manual

I-01529

Contents

	Page
1. Preface	3
1.1 Preparations prior to use	3
1.1.1 Inspection	3
1.1.2 Storage	3
1.2 Confirmation prior to use	3
1.2.1 Power supply	3
1.2.2 Power supply cable	3
1.2.3 Setting of power supply frequency	3
1.2.4 Replacement of fuse	3
2. Name of Parts	4
2.1 Front panel	4
2.2 Rear panel	6
3. Operation	7
3.1 Power supply	7
3.2 Connection of measuring terminals	7
3.3 Cautions for measurement	8
3.3.1 When overlaying the DC voltage	8
3.3.2 Others	8
3.4 Connection of analog output	8
3.5 Key-lock	8
3.6 Changeover of display	9
3.6.1 Selection of display mode	9
3.6.2 Selection of ratio display	10
3.7 Changeover of resistance range	11
3.8 Changeover of voltage range	11
3.9 Zero adjustment	12
3.9.1 Key operation	12
3.9.2 Remote operation	12
3.10 Selection of sampling rate	12
3.11 Setting of power source frequency	13
3.12 Setting of voltage limiter	13
3.13 Comparator action	14
3.13.1 Conditions of comparison	14
3.13.2 Comparator output	14
3.13.3 Setting method	15
3.13.4 Display mode of range lamps	18
3.14 Buzzer	19
3.14.1 Setting method	19
3.15 Manual mode	20
3.16 Memory mode	20
3.16.1 Selection of memory	20
3.17 Setting of memory	21
3.18 Detection of disconnection and self-check	23
3.18.1 Operation	23
4. Remote control	24
4.1 Remote connector	24
4.1.1 Pin operation	24
4.1.2 Remote operation of memory mode	25
4.1.3 Timing chart of remote control	26
4.2 Remote control (input and output terminal blocks)	28
5. Setting method	29
5.1 Resistance measurement	29
5.2 Ratio display function	30
5.2.1 Setting of referential resistance value and deviation	31
5.3 Voltage measurement	32
5.4 Character display	32
6. Use in panel-mount	33
6.1 Assembly drawing	33
6.2 External dimensions when fitted with panel-mount bracket	33
7. Extension of lead wires	34
8. Calibration	35
8.1 Things to prepare	35
8.2 Calibration	35
8.2.1 Calibration of resistance measurement	35
8.2.2 Calibration of voltage measurement	36
8.2.3 Calibration of analog output	36
9. Specifications	37
9.1 Model name	37
9.2 Measuring range and accuracy	37
9.3 General specifications	38
9.4 Table of initial setting (at delivery from factory)	39
9.5 External dimensions	39
9.6 Option	39
10. Maintenance and calibration	40

1. Preface

We thank you for your purchase of our product. Please take care that this instruction manual is certainly delivered to the person in charge to operate the product. For proper use of the product, please carefully read this manual prior to the initial operation.

CAUTION

- To avoid break-down, malfunction or deterioration of life of the product, do not use it in such places where:
 - ◆ exposed to rain, water drops or direct sunlight.
 - ◆ high temperature or humidity, heavy dust or corrosive gas.
 - ◆ affected by external noise, radio waves or static electricity.
 - ◆ where there is constant vibration or shock.
- Do not use the product dismantling or modifying it.

1.1 ●Preparations prior to use

1.1.1 Inspection

When the meter is delivered, please check whether it conforms to the required specifications and has not been damaged in transit. If there is any damage on the meter or it does not work in conformity with the specifications, please inform us of the model and product name.

1.1.2 Storage

In case of storing the meter for a long time, store it at the place of low humidity and where it is not exposed to the direct sunlight.

1.2 ●Confirmation prior to use

1.2.1 Power supply

Use the meter with the power source voltage within 90~250VAC and the frequency 50/60Hz. When connecting the power supply cable, confirm that the power supply switch is turned OFF.

1.2.2 Power supply cable

The plug of power supply cable connected to the meter is for 100VAC use. When the meter is used with 200VAC, replace the plug with appropriate one for 200VAC use. Please connect the power supply cable to the power supply connector on the rear panel of the meter. The plug of power supply cable has 3 pins and the round shape pin in the center is for grounding. When connecting the meter to the receptacle with an adapter attached to the plug, be sure to connect the earth wire of the adapter to the external earth line for grounding.


1.2.3 Setting of power supply frequency

The power supply frequency setting is necessary to eliminate the induced voltage of power supply. Setting the suitable power frequency of the power supply in instrument before use.

1.2.4 Replacement of fuse


A fuse of 250V/2A for the power source is mounted at the delivery from factory.

A socket of the fuse is incorporated in the input connector of the power supply line. In advance to connecting the power supply cable, confirm the rate of the fuse, removing the cap of fuse holder and taking the fuse out. In total two fuses, including a spare one, are put inside the fuse cap. The fuse on this side (spare fuse) can be removed by pushing it toward right or left, and the fuse another side downward.



2. Name of parts

2.1 ●Front panel




- ① Measuring terminals SENSE Hi : Input terminal of resistance measurement and + terminal of voltage measurement.
SENSE Lo : Input terminal of resistance measurement and - terminal of voltage measurement.
SOURCE Hi : Current output terminal.
SOURCE Lo : Current output terminal
(Connected to SENSE Lo at the voltage measurement.)
- ② **[FUNC]** key (SET) Key to changeover the resistance/ratio display in resistance measurement.
At ratio display : RATIO lamp is lit up.
At resistance display : OHM lamp is lit up.
(In manual mode, the power source frequency and the limit can be set.)
(In memory mode, the setting of memory can be done.)
- ③ **[RATE]** key (MAN'L/MEM) Key to select a sampling rate.
(Key to changeover the memory/manual mode. MAN'L lamp is lit up in manual mode.)
- ④ **[0 ADJ]** key (ONLINE) Key to ON/OFF the zero-adjust function.
0 ADJ lamp is lit up while the zero-adjust function is working.
(On-line key of the GP-IB, RS-485 and RS-232C.)
- ⑤ **[SHIFT]** key (LOCK) Blue key becomes effective while the SHIFT lamp is lit up.
While the SHIFT lamp is lit up, it can be turned off by pressing this key.
(The key prohibits the key operation on the front panel. The pressing of the key for 3 seconds or more allows prohibition or cancellation. During the prohibition, the LOCK lamp is lit up.)
- ⑥ **[VIEW]** key Key to select the display mode.
- ⑦ **[RANGE]** key (BUZZER) Key to select the range of resistance or voltage.
The resistance range $30\text{m}\Omega \sim 3\text{k}\Omega$ or AUTO range can be selected.
The voltage range 5V or 50V can be selected.
(Key to enter the setting of buzzer mode and sound volume.)
- ⑧ **[SEL]** key (COMP SET) Key to changeover the setting items.
- ⑨ **[▶]** key Key used for various setting.
- ⑩ **[▲]** key Key used for various setting.

⑪ MAN'L lamp 0 ADJ lamp ONLINE lamp LOCK lamp SHIFT lamp	Lit up in manual mode and turned off in memory mode. Lit up while the zero-adjust is in working. Lit up when remote controlled. Lit up while key-locked. Interlocked with SHIFT key. While the lamp is lit up, the key functions change to those of blue letters ().
⑫ OHM lamp RATIO lamp	Lit up in resistance measurement. Lit up in ratio display.
⑬ LIM lamp	Lit up when the limiter of open voltage is not limited to the peak 20mV.
⑭ F lamp M lamp S lamp	Displays in blinking when the sampling rate is FAST. Displays in blinking when the sampling rate is MEDIUM. Displays in blinking when the sampling rate is SLOW. (The lamps become steady light during the hold status.)
⑮ HI lamp GO lamp LO lamp	Red LED is lit up when the measured resistance value is at high limit or above. Green LED is lit up when the resistance measurement is good judgement. Red LED is lit up when the measured resistance value is at low limit or below.
⑯ FL lamp PS lamp	Red LED is lit up when the measured voltage value is at high limit or above or, low limit or below. Green LED is lit up when the voltage measurement is good judgement.
⑰ Unit lamp	The unit of the data being indicated on the main display is lit up. For resistance : k Ω , Ω , m Ω For ratio : % For voltage : V
⑱ Range lamp AUTO lamp	In resistance display mode: The measuring range is lit up The comparator range is lit up in blinking. In voltage display mode: Turned off. In resistance voltage display mode: The resistance measuring range is lit up. Lit up in AUTO range measurement.
⑲ Main display section	The measured values and various characters are displayed. In Rr mode : The measured resistance value is displayed. In Vv mode : The measured voltage value is displayed. In RV mode : The measured resistance value is displayed.
⑳ No. display	The memory number is displayed in memory mode. During the setting of buzzer, power source frequency / limit, the characters being set are displayed.
㉑ Ω % lamp V lamp	Lamp to inform the content of HI SET and LO SET display. Ω % lamp is lit up in Rr mode. V lamp is lit up in Vv mode and RV mode.
㉒ HI SET display	The comparator's high limit and various characters are displayed. In Rr mode : The high limit of resistance comparator or the referential resistance value of ratio measurement is displayed. In Vv mode : The voltage comparator's high limit is displayed. In RV mode : The voltage side measurement value is displayed.
㉓ LO SET display	The comparator's low limit and various characters are displayed. In Rr mode : The low limit of resistance comparator or the range of ratio measurement is displayed. In Vv mode : The voltage comparator's low limit is displayed. In RV mode : Turns off.

Note: The (blue letter) keys become effective while the SHIFT lamp is lit up.

2.2 ●Rear panel



②④ Rear measuring terminals

Respectively common with:

SENSE Hi : (SENSE Hi) on the front panel.
 SENSE Lo : (SENSE Lo) on the front panel.
 SOURCE Hi : (SOURCE Hi) on the front panel.
 SOURCE Lo : (SOURCE Lo) on the front panel.

②⑤ Power supply connector

The attached power supply connector is to be used.
 Be sure to use the meter with the specified power source voltage and frequency.
 A fuse of 250V 2A must be used.

②⑥ Power source switch ON/OFF switch of the power supply.

②⑦ REMOTE connector Connector for the remote control.


②⑧ Input and output terminal blocks Terminals for input of hold and reset, and for output of resistance comparator.

②⑨ Analog output terminals Terminals to output the DC voltage proportional to the measured value. ZERO : ZERO volume of the analog output MAX : MAX volume of the analog output

③⑩ Inlet for interface board Section to fit an optional interface board.

3. Operation

3.1 ●Power supply



After confirming that the power supply switch on the rear panel is turned OFF, connect the power supply plug into the receptacle and turn ON the power supply switch. The meter promptly enters into operable condition but it is recommended to have a pre-heating time for 30 minutes or more. The meter is provided with the function to retain the parameters, so it stores the status of the following parameters even when the power supply is turned OFF.

- (1) Measuring function, display mode and measuring range.
- (2) Set values of comparator (30 program memories).
- (3) Key-lock status.
- (4) Buzzer status.
- (3) Zero-adjust condition.

3.2 ●Connection of measuring terminals

Make a connection to the measuring terminals on the front panel (or rear panel) as the **Fig. 3.2.1** shows.




Fig. 3.2.1

Note: If the noise enters the measuring terminals, it may cause the display to widely fluctuate or the auto-range action to be unstable. Ensure to use the shielded wire and connect the shield side to the SOURCE Lo. If all 4 wires are not connected properly, the displayed value may be fluctuated.

Please carry out plugging of the Kelvin clips (banana plug side) and the resistance meter as follows.




Fig.3.2.2 Connection of optional Kelvin clip (MODEL 5811-21B).

3.3 ●Cautions for measurement

3.3.1 When overlaying the DC voltage

Apply the voltage 60VDC or less.

After the measurement, the capacitor inside the meter is charged with voltage, so let the probe short-circuit for a few seconds to discharge it.


3.3.2 Others

A big error may occur when the samples with inductance or capacitance is measured.

If the meter is used near the source of noise (high frequency furnace, high noise power line, inverter power source etc.), such noise may enter the input line and affect the measurement.

Avoid the use in such a site or keep the sufficient distance from the source of noise.

3.4 ●Connection of analog output




The analog output proportional to the measured resistance value is output. (The analog data proportional to the resistance value is output even during the ratio display.)

Make a connection of the cable to the analog output terminal, applying the cable end treatment as the **Fig. 3.4.1** shows.

Push down the release knob with a screwdriver or else and insert the cable to the terminal.

Length to cut = 9~10mm



Applicable cable: AWG28~AWG32

Fig. 3.4.1

Data output	: 0~3VDC 0 display = 0V, 30000 display = 3.000V
Conversion system	: D/A conversion system
Resolution	: 1mV
Accuracy	: Accuracy of resistance measurement + 0.2% F.S.
Output terminal	: Screw-less terminal


3.5 ●Key-lock

The key-lock is the function to prohibit the key operation on the front panel so that the measuring condition is not altered.

While the key-lock is in operation, the LOCK lamp is lit up.

To operate the other keys, cancel the key-lock first.

It is not operable in the ONLINE or HOLD status.



How to key-lock

While the LOCK lamp is turned off, press **SHIFT** (LOCK) key for 3 seconds or more.

Reset of key-lock

While the LOCK lamp is lit up, press **SHIFT** (LOCK) key for 3 seconds or more.

3.6 ●Changeover of display

The content of display of main display section, HI SET and LOW set can be changed.
The changeover is allowed in the measuring condition. It is not operable in the memory mode, ONLINE or HOLD status.
The changeover to the ratio display is done with **FUNC** key.

3.6.1 Selection of display mode


Changeover of function

Every time the **FUNC** key is pressed, the resistance measurement and the ratio display alternate with each other. Select the resistance measurement. (No changeover is possible in the Vv mode.)

Changeover of VEW


Every time the **VEW** key is pressed, the display changes over.

- ① To display the resistance value and resistance comparator (Rr mode).
Select the Rr display with **VEW** key.




Rr mode

- ② To display the voltage value and voltage comparator (Vv mode).
Select the Vv display with **VEW** key.



Vv mode

- ③ To display the resistance and voltage value (RV mode).
Select the RV display with **VEW** key.



RV mode


For the content of each display mode, refer to the **Table 3.6.1** below.

Display mode	Main display	HI SET display	LO SET display	Ω % lamp	V lamp
Rr mode	Resistance measurement value	Resistance comparator High limit value	Resistance comparator Low limit value	Lit up	Turn off
(Ratio display)	Ratio display	Referential resistor	Deviation $\pm \Delta\%$		
Vv mode	Voltage measurement value	Voltage comparator High limit value	Voltage comparator Low limit value	Turn off	Lit up
RV mode	Resistance measurement value	Voltage measurement value	Turn off	Turn off	Lit up

Table 3.6.1

3.6.2 Selection of ratio display

To changeover the ratio display and the resistance display.



Ratio display

Changeover of function

Every time the **FUNC** key is pressed, the resistance measurement and the ratio display alternate with each other. In the resistance measurement, OHM lamp is lit up and the unit of resistance is lit up (one of k Ω , Ω or m Ω).

In the ratio display, RATIO lamp is lit up and % is lit up.

3.7 ●Changeover of resistance range


The measuring range (auto-range or manual range) of the resistance measurement is selected.

The operation is not allowed in the memory mode, ONLINE or HOLD status.

Selection of resistance measurement

Press the **VIEW** key and select the Rr or RV mode.

Changeover of resistance range



(1) Auto-range

- When the measured resistance value is 35000 (3500) or above, the range goes up, and when the value is 3000 (300) or less, the range goes down.

- The AUTO lamp and the lamp of detected range are lit up.

Note: Figures in the brackets are at F sampling rate.

Selection of auto-range

When pressed the **RANGE** key, the measuring range changes. Next to the 3kΩ range, the AUTO lamp is lit up and the range changes to the auto-range.

Note: When the auto-range is set, both resistance and voltage measurement change into auto-range action.

(2) Manual range

- The range is fixed range in between 30mΩ and 3kΩ.
- The lamp of selected range is lit up.

Selection of manual-range

Every time the **RANGE** key is pressed, the range lamp changes. Selected the required range.

3.8 ●Changeover of voltage range

The measuring range of the voltage measurement is selected.

The operation is not allowed in the memory mode, ONLINE or HOLD status.

Selection of voltage measurement

Press the **VIEW** key and select the Vv mode.

Selection of voltage range

(1) Auto-range

- Make the setting of auto-range in the resistance measurement.

The measuring range goes up when the measured voltage value is 50000 (5000) or more, and goes down when the measured value is 1000 (100) or less.

Note: Figures in the brackets are at F sampling rate.

(2) Manual range

- The range is fixed range 5V or 50V.

Selection of range

Every time the **RANGE** key is pressed, the measuring changes, and the lit up position of the decimal point changes.

(It can not be changed in the auto-range.)

12345 5V range

12.345 50V range

3.9 ●Zero adjustment

This is the function to suppress the resistance of the tool and so on used in the resistance measurement.


The data currently measured is memorized in the non-volatile memory as “zero adjustment value”, and afterwards, the value obtained by deducting the “zero adjustment value” from the measured value is displayed.

$$\boxed{\text{Display value}} = \boxed{\text{Measured value}} - \boxed{\text{Zero adjustment value}}$$

- It works in the resistance display and the resistance voltage display.
- The zero adjustment value works in every range.(It is memorized as the resistance value.)
- Remote operation is possible.
- External control by the interface of GP-IB, RS-232C or RS-485 is possible.

Note: This function is not operable during the HOLD status or setting.

3.9.1 Key operation



While the 0 ADJ lamp is turned off, press the **0 ADJ** key, the 0 ADJ lamp is then lit up and enters into the zero adjustment condition.

Cancellation of it can be done by pressing the **0 ADJ** key again.

⚠ CAUTION

- If [0ADJ] key is pressed at input open condition ($\infty\Omega$), it may cause the malfunction.
- If zero adjust is set at higher range, the measurement over might be caused in lower range.
- If [0ADJ] key is pressed on by mistake, the status can be recovered to normal stage by switching OFF the Zero adjustment function'.

3.9.2 Remote operation

While the 0 ADJ pin and COM of the REMOTE connector on the rear panel is short-circuited, the 0 ADJ lamp is lit up and the zero adjustment is in operable condition.

The measured resistance data at the moment when the 0 ADJ pin is short-circuited is memorized as zero adjustment.


When released the 0 ADJ pin, its working is cancelled.

Note: The zero adjustment action set by the key operation can be cancelled by making this pin OFF.

3.10 ●Selection of sampling rate

Selection of the sampling range is made by the key operation on the front panel. The external control by the interface of GP-IB, RS-232C or RS-485 is possible

Note: This function is not operable during the HOLD status or setting.



Key operation

Press the **RATE** key and the sampling rate changes.

S→M→F→S...


Sampling rate	Sampling LED	Sampling rate	
		50Hz	60Hz
S	S	1.56 times/sec.	1.88 times/sec.
M	M	6.25 times/sec.	7.52 times/sec.
F	F	50 times/sec.	60 times/sec.

3.11 ●Setting of power source frequency

In order to eliminate the affect of inductive voltage to invade the measurement line, the power source frequency is set.

The operation is not allowed in the memory mode, ONLINE or HOLD status.

When no key operation is made for 5 minutes during the setting, the meter returns to the measurement.



Press the **SHIFT** key, and the SHIFT lamp is lit up.

(Enters into the setting of power source frequency and voltage limit.)

Press (SET) key and the HI SET lamp blinks.

Adjust the power source frequency, pressing the **▲** key.

When the **SEL** key is pressed twice, the meter returns to the measurement.

HI SET display	Action
F - 50	Set to the power source frequency 50Hz
F - 60	Set to the power source frequency 60Hz


Note: Make sure to set the power source frequency. Otherwise, the accurate measurement can not be performed.

3.12 ●Setting of voltage limiter

By setting the voltage limiter to ON, it is possible to limit the voltage applied to the sample to be measured at the peak of 20mV. It protects the destruction of the oxide layer at the contact of the sample to be measured.

The operation is not allowed in the memory mode, ONLINE or HOLD status.

When no key operation is made for 5 minutes during the setting, the meter returns to the measurement.



Press the **SHIFT** key, and the SHIFT lamp is lit up.

(Enters into the setting of power source frequency and voltage limit.)

Press (SET) key and the HI SET lamp blinks.

Press the **SEL** key, and the LO SET lamp is lit up.

Set the voltage limiter, pressing the **▲** key.

When the **SEL** key is pressed, the meter returns to the measurement.

LO SET display	Action
L - off	Voltage limit set to OFF
L - on	Voltage limit set to ON

3.13 ●Comparator action

The comparator has two functions – one is the resistance comparator to compare the resistance values and the other is the voltage comparator to compare the voltage values.

The comparator compares the measured value and high/low limit, and output the judgement result.

A 30 pairs of the memory high and low limit values per pair can be memorized (No.1~No.30).

The judgement is output by open collector, simultaneously announcing by buzzer and lamp. (For the resistance comparator, a relay output can be provided at option.)

The memory can be selected by key operation or through remote connector.

The selection is also possible by the interface of GP-IB, BCD, RS-232C or RS-485.

Note: During the setting of high or low limit value, or calling of the memory, the sampling is stopped and the output is retained.

3.13.1 Condition of comparison

Resistance comparator

Display value \geq High limit value (HI SET)	HI output
High limit value (HI SET) $>$ Display value $>$ Low limit value (LO SET)	GO output
Display value \leq Low limit value (LO SET)	LO output

Note: The comparator makes the comparison including the range.

Example:

In case that the high limit value is set to 100.00m Ω (300m Ω range), and when 10.00 Ω is displayed in the measuring range is 300 Ω , the HI output is given.

Voltage comparator

Display value \geq High limit value (HI SET) or	
Display value \leq Low limit value (LO SET)	FL output
High limit value (HI SET) $>$ Display value $>$ Low limit value (LO SET)	PS output

3.13.2 Comparator output

Resistance comparator

Open collector output or relay contact output is output at the input/output terminals on the rear panel.

(Refer to the article 4.2)

Display: HI and LO: Red, GO: Green

Voltage comparator

Open collector output is output at the REMOTE connector on the rear panel.
(Refer to the article 4.1)

Display: FL: Red, PS: Green

3.13.3 Setting method

No setting is possible during the ONLINE, when externally controlled by the BCD data output interface or in the HOLD status.

When no key operation is made for 5 minutes during the setting, the meter returns to the measurement.

Adjustable range: High limit Resistance : 0~35000
Voltage : -50000~50000
Low limit Resistance : 0~35000
Voltage : -50000~50000



The unit and the decimal point are set with the **[RANGE]** key.

The content of the comparator setting is different depending upon the display mode.

Display mode	Setting items
Rr mode	Resistance comparator, high and low limit
Vv mode	Voltage comparator, high and low limit
RV mode	Resistance comparator, high and low limit Voltage comparator, high and low limit

Note: When the setting is for the resistance comparator, in the ratio display mode, the items to set are deviation ($\pm \Delta\%$).

Setting of resistance comparator (Rr mode)



Changeover to manual mode

- ① (Refer to the article 3.15)

Changeover to resistance display

- ② Changeover to Rr mode with the **[VIEW]** key.
(Refer to the article 3.6)

Setting of high limit value

- ③ Press the **[SEL]** key.

The highest digit of HI SET display blinks.
Set the numeral with the **[▶]** or **[▲]** key.
The selected digit blinks with the **[▶]** key.

Setting of low limit value

- ④ Press the **[SEL]** key.

The highest digit of LO SET display blinks.
Set the numeral with the **[▶]** or **[▲]** key.
The selected digit blinks with the **[▶]** key.

Setting of comparator range

- ⑤ Set with the **[RANGE]** key

The selected range lamp blinks.

Note: The decimal point automatically changes depending upon the range.



Finish of the setting

- ⑥ The setting can be finished by pressing the **[SEL]** key during the setting of low limit.

Note-1: When returned to the measurement and, the measuring range and comparator range are different, the range lamp of the comparator range is lit up.

Note-2: When the setting of high or low limit is out of the range, Err is displayed for a while at the setting item in question, and then returns to the setting of high or low limit.

Setting of voltage comparator (Vv mode)



Changeover to voltage display

- ① Changeover to Vv mode with the **VIEW** key.
(Refer to the article 3.6)

Setting of high limit value

- ② Press the **SEL** key.
The highest digit of HI SET display blinks.
Set the numeral with the **▶** or **▲** key.
The selected digit blinks with the **▶** key.

Setting of low limit value

- ③ Press the **SEL** key.
The highest digit of LO SET display blinks.
Set the numeral with the **▶** or **▲** key.
The selected digit blinks with the **▶** key.

Setting of comparator range


- ④ Set with the **RANGE** key
The selected range is known by the position of decimal point being lit up.
5V range : Decimal point at 10^4 is lit up.
50V range : Decimal point at 10^3 is lit up.
Note: The decimal point automatically changes depending upon the range.

Finish of the setting

- ⑥ The setting can be finished by pressing the **SEL** key during the setting of low limit.
Note: When the setting of high or low limit is out of the range, Err is displayed for a while at the setting item in question, and then returns to the setting of high or low limit.

Setting of resistance voltage comparator (RV mode)


In case of the RV mode, the setting is made sequentially for the resistance comparator and the voltage comparator.



Setting of resistance comparator


Setting of HI SET

SEL key.



Setting of LO SET


SEL key.



Setting of voltage comparator

Setting of HI SET

SEL key.



Setting of LO SET

3.13.4 Display mode of range lamps

The model 3566 is designed to display both selected measuring range and comparator set value. When the comparator set value is different from the selected measuring range, the comparator set value is displayed in blinking.

Examples: 1. When the measuring range and comparator set value are different.

Measuring range	3k Ω range is selected.
Comparator set value	HIGH 300.00 Ω LOW 100.00 Ω (range is 300 Ω)
Range display	3k Ω steadily lighting 300 Ω blinking

2. When the measuring range and comparator set value are same.

Measuring range	300 Ω range is selected.
Comparator set value	HIGH 300.00 Ω LOW 100.00 Ω (range is 300 Ω)
Range display	300 Ω steadily lighting


3. In AUTO range.

Measuring range	AUTO 3k Ω range is selected. (selected by input resistance)
Comparator set value	HIGH 300.00 Ω LOW 100.00 Ω (range is 300 Ω)
Range display	AUTO 3k Ω steadily lighting 300 Ω blinking

3.14 ● Buzzer

The setting of the buzzer is made with the (BUZZER) key on the front panel.
 During the setting of buzzer, the sampling is stopped and the comparator output is held.
 The setting is not allowed in the memory mode, ONLINE or HOLD status.
 When no key operation is made for 5 minutes during the setting, the meter returns to the measurement.

3.14.1 Setting method




Setting of buzzer action

Press the **SHIFT** key.
 The SHIFT lamp will then light up.
 Press the (BUZZER) key.
 It changes to the buzzer setting and **b₃** is displayed on the No. display, making HI SET blink.
 The buzzer action is displayed on the HI SET, and the buzzer sound on the LO SET.

Selection of buzzer action

Select the buzzer action with the **▲** key.




Display	Action
OFF	Buzzer OFF (buzzer does not sound).
GO	Buzzer sounds when the resistance judgement is GO.
HI nG	Buzzer sounds when the resistance judgement is HI.
LO nG	Buzzer sounds when the resistance judgement is LO.
HI LO	Buzzer sounds when the resistance judgement is HI or LO.
PASS	Buzzer sounds when the voltage judgement is PS.
FAIL	Buzzer sounds when the voltage judgement is FL.
Good	Buzzer sounds when the resistance judgement is GO and the voltage measurement is PS.
nG	Buzzer sounds when the resistance judgement is HI or LO, and the voltage judgement is FL.

Adjustment of sound volume

When the **SEL** key is pressed during the setting of buzzer action, it becomes the setting of buzzer sound level and the buzzer sounds.
 By pressing the **▲** key, the sound level and its indication change.
 The buzzer sound level is adjustable in 10 steps.


Finish

By pressing the **SEL** key in the buzzer sound level setting, the buzzer setting can be finished and the meter returns to the measurement.



3.15 ●Manual mode

In this mode, the changeover of function, measuring range or display mode is possible. It can not be changed over to the manual mode when the meter is remote controlled and while the ONLINE is lit up.



Operation

Press the **SHIFT** key and while the SHIFT lamp is lit up, changeover the manual mode / memory mode with the (MAN'L/MEM) key.

During the manual mode, MAN'L lamp is lit up and the No. display (indication of memory number) turns off.


3.16 ●Memory mode

In this mode, it is possible to select a memory of the measuring conditions from among 30 memories stored in the meter and to perform the measurement according to the conditions of the selected memory.

The sampling rate is common setting.

3.16.1 Selection of memory

● Procedures on the front panel



Enter the memory mode

- ① Press the **SHIFT** key.
The SHIFT lamp is lit up.
- ② Press the (MAN'L/MEM) key, and the mode changes to the memory mode, displaying the memory number.
The MAN'L lamp turns off.

Call up of memory

- ③ Press the **SEL** key, then the memory number changes and the content of the selected memory is called up. The measurement and judgement are carried out under the measurement conditions of the memory called up.

Finish of the memory mode

- ④ Press the **SHIFT** key.
The SHIFT lamp is lit up.
- ⑤ Press the (MAN'L/MEM) key and the mode changes to the manual mode, lighting the MAN'L lamp up.

● Procedures by remote operation

Refer to the remote operation of memory mode (article 4.1.2)

3.17 ●Setting of memory

The setting of memory is made, moving to the memory mode with key operation.
When the memory is selected through the REMOTE connector, the setting is not allowed.
Make the setting of memory with key operation after canceling it.

The items of the memory setting are following 4 items.

- Setting of comparator (resistance/voltage comparator (high and low limit value))
- Display mode (resistance display, voltage display, resistance voltage display)
- Function of resistance measurement (resistance measurement, ratio display)
- Measuring range (resistance measuring range, voltage measuring range)

Note:

- No setting is possible in the hold status.
- No setting is possible while the ONLINE is lit up by the remote operation.
- During the setting, the sampling is stopped and the comparator output is held.
- When no key operation is made for 5 minutes during the setting, the meter returns to the measurement of the memory mode.

Enter the memory mode

Enter the memory mode with the **[SHIFT]** and (MAN'L/MEM) key. (Refer to the article 3.16)

Setting of memory

Press the **[SHIFT]** key, and the SHIFT lamp is lit up.
Press the (SET) key, then the display mode blinks on the measurement display and the memory number blinks.

Selection of memory No.




Select the memory No. pressing the **[▲]** key.

Selection of display mode


Select the display mode setting with the **[VIEW]** key.
The display mode is indicated on the main display section. The measuring range is displayed together in the Vv mode.

Setting of ratio display

Make the display to Rr.
Select the ratio display with the **[FUNC]** key
When the ratio display is selected, the RATIO lamp is lit up.




Rr display




Vv display (50V range)





Vv display (5V range)



RV display





Setting of measuring range

- Setting of resistance measuring range
Changeover the display to Rr or RV with the **VIEW** key.
Select the resistance measuring range with the **RANGE** key. The lamp of the selected range is lit up.

Note: In case that the resistance measuring range and the comparator range are different, the comparator range is displayed in blinking.
AUTO lamp is lit up on AUTO range.

- Setting of voltage measuring range
Select the Vv display with the **VIEW** key.
Select the measuring range with the **RANGE** key. The selected range is indicated on the main display section.
(AUTO range can not be set.)

Setting of comparator

Press the **SEL** key, and the highest digit of the HI SET blinks to make the comparator setting.
(Refer to the article 3.13.3)


Finish

Press sequentially the **SHIFT** key and the (SET) key, then the memory setting finishes and the meter returned to the measurement under memory mode.


3.18 ●Detection of disconnection and self-check

Detection for the disconnection of the measuring lead SOURCE and SENSE is made.
When the disconnection is detected, the CC ERR output transistor turns ON.
The CC ERR output also turns ON when the measuring current does not flow due to open circuit etc.

Note: During the detection of disconnection is in operation, the sampling is stopped and the comparator output is held.



3.18.1 Operation



Preparation

Connect the measuring lead to the meter.
Connect or short-circuit the sample to be measured to the tip of the measuring lead.

Start of detection of disconnection

Short-circuit the SW input on the REMOTE connector to COM.

The measurement display shows *rS LL*.

Result of detection of disconnection

When there is no error detected, *rSEnd* is displayed on the display section.


When the disconnection is detected, the following displays are given.

ErrSo : Disconnection of SOURCE side lead

ErrSE : Disconnection of SENSE side lead

Finish of detection of disconnection


Open the SW input on the REMOTE connector.





4. Remote control

4.1 Remote connector

4.1.1 Pin operation



Input circuit ("L" =1.5V or less "H" =3.5~5V $I_{IL} \leq -1\text{mA}$)



(D-sub 15 pin)

Pin No.	Signal	Function
1	0 ADJ input	By making it ON, the zero adjustment is done. (Refer to the article 3.9)
2	NC	Vacant pin.
3	MEM input	By making it ON, the memory mode is selected.
4	TRIG input	By making it ON once during the hold status, one sampling is made and the judgement result is output. Min. ON time: 5ms
5	SW input	By making it ON, the detection of disconnection and self-check are started.
6	EOC output	Transistor output becomes ON when the AD conversion is finished.
7	CC ERR output	When the current does not flow due to the opening etc. of SOURCE terminal, and when the error is detected in the detection of disconnection / self-check, the transistor output is made ON.
8	COM	Common for input and output.
9 10 11 12 13	M-SEL0 M-SEL1 M-SEL2 M-SEL3 M-SEL4	Memory No. is input in the memory mode to call up the memory.
14	FL output	FL output of voltage comparator, makes the transistor output ON.
15	PS output	PS output of voltage comparator, makes the transistor output ON.

4.1.2 Remote operation of memory mode

- ① While the MEM signal is made ON, the mode is memory mode.
 - Moves to the memory mode and the ONLINE lamp is lit up.
 - The selected memory No is displayed.

Note: When the memory No out of the code is selected, it is not allowed to enter the memory mode. Make an input of the code 1~30.
- ② Input the code of memory No and call up the memory.

Table of memory code

Signal	Weight	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
M-SEL0	1		○		○		○		○		○		○		○		○
M-SEL1	2			○	○			○	○			○	○			○	○
M-SEL2	4					○	○	○	○					○	○	○	○
M-SEL3	8									○	○	○	○	○	○	○	○
M-SEL4	16																

Signal	Weight	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
M-SEL0	1		○		○		○		○		○		○		○		○
M-SEL1	2			○	○			○	○			○	○			○	○
M-SEL2	4					○	○	○	○					○	○	○	○
M-SEL3	8									○	○	○	○	○	○	○	○
M-SEL4	16	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

○ : Makes ON.


Blank : Turns OFF.

Note: The input of 0 or 31 makes no change.

- ③ Turn the MEM signal OFF.
 - Moves to the manual mode and the ONLINE lamp is turned off.
 - Finish the memory mode.

4.1.3 Timing chart of remote control


(1) Measurement action




Tsh = Hold, trigger response time

Power source frequency set →	50Hz	60Hz
Sampling rate ↓		
F	13~36ms	12~28ms
M	90~170ms	70~143ms
S	570~650ms	485~540ms

(2) Zero adjustment




(3) Changeover of memory (changeover of memory/manual is same)



T_s = Sampling rate

(4) Response time



T_1 = Stabilization time

T_2 = Judgement time


Response time = $T_1 + T_2$

	Sampling rate = F		Sampling rate = M		Sampling rate = S	
	50Hz	60Hz	50Hz	60Hz	50Hz	60Hz
T_1	48ms	48ms	250ms	250ms	250ms	250ms
T_2	13~36ms	12~28ms	90~170ms	78~143ms	570~650ms	485~540ms
$T_1 + T_2$	61~84ms	62~76ms	340~420ms	328~393ms	820~900ms	735~790ms


4.2 Remote control (input and output terminal blocks)

Terminal arrangement

Open collector output



Relay contact output



(1) HOLD terminal (Hold)

By short-circuiting the HOLD terminal on the rear panel to the COM terminal, the display value, comparator output and BCD data output are held. The hold operation prohibits the operation of all the keys.

(2) Reset terminal (Reset)

By short-circuiting the RST terminal on the rear panel to the COM terminal, the comparator output is reset and the comparator display is turned OFF.

○ One sampling hold action

It is possible to do the one sampling hold with the HOLD being short-circuited and making ON/OFF of the RST. Do the one sampling hold with the manual range. In case of the auto-range, it may cause an error.


(3) Comparator output

Open collector output : HI, GO, LO, all sink type
30V 30mA max.

Relay contact output : HI, GO, LO, 1a contact for each
250VAC 1A resistive load

5. Setting method

5.1 ●Resistance measurement



Operating procedure

- ① Set the meter to manual mode.
(Refer to the article 3.15)
- ② Select the Rr mode with the **VIEW** key.
(Refer to the article 3.6)
- ③ Select the resistance measurement with the **FUNC** key. When the resistance measurement is selected, the OHM on the function display is lit up. (RATIO is turned off.)
At this moment, the main display section displays the resistance value and either one of the measuring units kΩ, Ω or mΩ is lit up.
- ④ Select the measuring range with the **RANGE** key. Every time the **RANGE** key is pressed, the measuring range changes.
In the auto-range, AUTO lamp and the detected measuring range are lit up.
The decimal point is automatically lit up depending upon the selected range.
- ⑤ Make the setting of comparator.
(Refer to the article 3.13.3)
- ⑥ Connect the sample to be measured to the resistance measuring cable, then the measured resistance value is displayed.
In case that the measured resistance exceeds the measuring range (35000), **UUUUU** blinks to inform the over-range.
In case of the auto-range, the range goes up when exceeded the 35000. Also, the range goes down when the value becomes 3000 or less.

5.2 ●Ratio display function

This is the function to compare the measured resistance value R_X to the referential resistance value R_S , and indicates its ratio to the referential resistance value in percentage. Also, the comparative judgement by the deviation ($\pm \Delta\%$) is possible.

Display range : 0.0~199.9%


Adjustable range of deviation ($\pm \Delta\%$) : 0.0~199.9%

Calculation formula

$$X = \frac{R_X}{R_S} \times 100\%$$

$$\Delta = \left[\frac{R_X}{R_S} - 1 \right] \times 100\%$$

X : Ratio (%)
 R_S : Referential resistance value (Ω)
 R_X : Measuring resistance value (Ω)
 Δ : Deviation (%)



Operating procedure

- ① Select the Rr mode with the **VIEW** key.
(Refer to the article 3.6)
- ② Select the resistance measurement with the **FUNC** key.
- ③ Select the measuring range with the **RANGE** key.
- ④ Connect the sample to be measured to the resistance measuring cable, then the measured resistance value is displayed.
- ⑤ Select the ratio display with the **FUNC** key.
When the ratio display is selected, RATIO on the function display is lit up. (OHM is turned off.)
At this moment, the main display section displays the calculated ratio value and the measuring unit % is lit up.
The referential resistance value is displayed on the HI SET, and the deviation ($\pm \Delta\%$) is displayed on the LO SET.
In the ratio display, the main display section and the lowest digit of the LO SET are turned off.
In case that the measured resistance exceeds the measuring range of the calculation result is 200.0% or above, **■■■■■** blinks to inform the over-range.
- ⑥ Make a setting of the referential resistance and deviation ($\pm \Delta\%$). (Refer to the article 5.2.1)

Note: When changed over to the ratio display, the high limit of the resistance comparator becomes the referential resistance as it is. Also, in case of the memory mode, the low limit of the resistance comparator becomes the deviation ($\pm \Delta\%$) as it is.

5.2.1 Setting of referential resistance value and deviation


Move to the ratio display function

- ① Refer to the operating procedure.

Setting of referential resistance value

- ② Press the **[SEL]** key.
The highest digit of the REF display section blinks.
Set the numeral with the **[▶]** and **[▲]** key.
The digit selected with the **[▶]** key blinks.
- ③ Set the range of referential resistance value with the **[RANGE]** key.


Adjustable range : 00000~35000



Setting of deviation ($\pm \Delta\%$)

- ④ Press the **[SEL]** key.
The highest digit of the deviation ($\pm \Delta\%$) display section blinks.
Set the numeral with the **[▶]** and **[▲]** key.
The digit selected with the **[▶]** key blinks.

Adjustable range : 0.0~199.9%




Finish

- ⑤ Press the **[SEL]** key.

Note: When the content tried to be set is out of the adjustable range, the Err is displayed for a while at the setting item out of the range, and then return to ③ or ④.

5.3 ● Voltage measurement



Operating procedure

- ① Select the voltage measurement display with the **VIEW** key.
(Refer to the article 3.6)
- ② Select the measuring range with the **RANGE** key. Confirm the measuring range with the position of decimal point.
Note: When the resistance measurement range is set to AUTO, the AUTO is lit up and the voltage measurement range also becomes auto-range operation.
At this moment, it is not possible to make the setting of range with key operation.
- ③ Make the setting of comparator.
(Refer to the article 3.13.3)
- ④ Connect the sample to be measured to the resistance measuring cable, then the measured voltage is displayed.
In case that the measured voltage exceeds the 50000, **UUUUU** blinks to inform the over-range.
In case of the auto-range, the range goes up when exceeded the 50000. Also, the range goes down when the value becomes 1000 or less.

Examples of range display

12.345

At 50V range

0.1234

At 5V range


5.4 ● Character display

Display	Name	Explanation
UUUUU	Error 0	When the measurement is over-range.
ErrSO	Error SO	At SOURCE open (disconnection being detected).
ErrSE	Error SE	At SENSE open (disconnection being detected).
SEF	Set	Setting of memory.
rS CC	Test CC	Start of detection of disconnection and self-check (disconnection being detected).
rSEnd	Test end	Finshd of detection of disconnection and self-check (disconnection being detected).
Err	Setting error	Blinks for about 1 second when the setting item is out of the range.
r-SER	R set	In process of setting of the resistance comparator.
v-SER	V set	In process of setting of the voltage comparator.

6. Use in panel-mount


6.1 ●Assembly drawing

When the meter is used by panel-mounting, use the optional panel-mount bracket.



- ① Remove the feet (4 parts) at the bottom of the meter.
 - ② Fix the panel-mount bracket to both side of the meter (M4 × 15 flat screw)
 - ③ Insert the meter from the front of the panel and fix it to the panel with the fixing metal.
- Note:** In case that the meter is installed to the chassis, utilizing the bottom screw taps of the meters, keep the length of screw at 6mm + thickness of chassis (mm).

6.2 ●External dimensions when fitted with panel-mount bracket



7. Extension of lead wires

●Cautions of the extension of lead wires

- ① Make the extension by 4 terminals system (2 wires for SENSE, 2 wires for SOURCE).
If the wiring is made by 2 wires, the wiring or contact resistance is included in the measured value, having caused an incorrect measurement value.
- ② Make the wiring so that the forked section of the lead is as short as possible.
- ③ Keep the measuring distant from the metallic part. If it is close to the metallic part, it may cause an inaccurate measurement due to the eddy current.
- ④ When the lead wire is extended, take care that the lead wire resistance does not exceed the tolerable range specified in the following table.

Tolerable range of lead wire resistance of SOURCE lead

Resistance range	Voltage limit	
	ON	OFF
30mΩ	500mΩ	2Ω
300mΩ	7Ω	17Ω
3Ω	50Ω	70Ω
30Ω	550Ω	600Ω
300Ω	160Ω	160Ω
3kΩ	150Ω	150Ω

8. Calibration

8.1 ● Things to prepare

When calibrate the 3566, please prepare the following devices for the calibration.

Standard resistors for calibration of resistance measuring range:

30m Ω , 300m Ω , 3 Ω , 30 Ω , 300 Ω , 3k Ω , 30k Ω


Standard voltage generator for calibration of voltage measuring range: 5V, 50V

Voltmeter for analog output

Note: Select the calibration devices whose accuracy satisfies the accuracy of 3566.

8.2 ● Calibration

8.2.1 Calibration of resistance measurement




- ① Turn OFF the power supply switch, and keep pressing the **FUNC** key and the **RATE** key together, turn ON the power supply switch again. **CAL** is displayed on the HI SET display, and the meter enters the calibration mode.
- ② When entered the calibration, it is the resistance calibration. In the resistance calibration, the OHM lamp and the Ω % lamp are lit up.
- ③ Make a connection of the standard resistor with the lead wires as the figures show. Connect the standard resistor to suit each range.
- ④ By pressing the **▶** key, ZERO is calibrated, and MAX by pressing the **▲** key. Calibrate each range selecting it by **RANGE** key. When the calibration is properly made, **CAL** is displayed in blinking on the display section for a while. If the **Err** is displayed, it is exceeding the range which can be calibrated. Connect a right resistor.
- ⑤ The standard resistance value and their display value to connect each range are as the **Table 7.2.1** shows.


Range	Standard resistance value	ZERO display value	Max display value
30m Ω	30m Ω	0.000m Ω	30.000m Ω
300m Ω	300m Ω	0.00m Ω	300.00m Ω
3 Ω	3 Ω	0.0000 Ω	3.0000 Ω
30 Ω	30 Ω	0.000 Ω	30.000 Ω
300 Ω	300 Ω	0.00 Ω	300.00 Ω
3k Ω	3k Ω	0.000k Ω	3.0000k Ω

Table 7.2.1

- ⑥ When the calibration is finished, turn OFF the power supply and cancel the calibration mode. When the meter is powered ON again, it returns to measurement.



8.2.2 Calibration of voltage measurement




- ① Turn OFF the power supply switch, and keep pressing the **[FUNC]** key and the **[RATE]** key together, turn ON the power supply switch again. **CAL** is displayed on the HI SET display, and the meter enters the calibration mode.
- ② When entered the calibration, it is the resistance calibration. The **[VIEW]** key allows the changeover between the voltage calibration and the resistance calibration. For the voltage calibration, the V lamp is lit up.
- ③ Make a connection of the standard voltage generator with the lead wires as the figure shows. Connect the input voltage to suit each range.
- ④ By pressing the **[▶]**, ZERO is calibrated, and MAX by pressing the **[▲]** key. Calibrate each range selecting it by **[RANGE]** key. When the calibration is properly made, **CAL** blinks on the display section for a while. If the **Err** is displayed, it is exceeding the range which can be calibrated.
- ⑤ The voltage to connect each range are as the **Table 7.2.2** shows.

Range	ZERO calibration voltage	Max calibration voltage
5V	0.0000V	5.0000V
50V	0.000V	50.000V


Table 7.2.2

- ⑥ When the calibration is finished, turn OFF the power supply and cancel the calibration mode. When the meter is powered ON again, it returns to measurement.



8.2.3 Calibration of analog output

- ① The analog output is calibrated in the resistance measurement. Press the **[VIEW]** key to make the Rr mode.
- ② Connect the voltmeter to the analog output terminal. Connect also the Kelvin clip to the resistance measuring input.
- ③ Make the measurement display 0, and adjust the output voltage to 0.000V with the ZERO volume. (When the red and black clips are connected in the range 3 Ω or 30 Ω , the display becomes 0 Ω .)
- ④ Make the measurement display 30000, and adjust the output voltage to 3.000V with the MAX volume. (For the over-range, 3.5000V is output.)



9. Specifications

9.1 ●Model name

Model name	Content
3566 -□	No data output
3566-01-□	With GP-IB (Discontinued September 2014)
3566-03-□	With BCD data output (TTL level)
3566-04-□	With BCD data output (open collector)
3566-05-□	With RS-232C
3566-06-□	With RS-485

□ : Judgement output
 Nil : Open collector NPN
 RY : Relay output

9.2 ●Measuring range and accuracy

■Resistance measurement (At SLOW and MEDIUM sampling)

Measuring range	30mΩ	300mΩ	3Ω	30Ω	300Ω	3kΩ
Resolution	1μΩ	10μΩ	100μΩ	1mΩ	10mΩ	100mΩ
Measuring current	7.4mA	1mA	100μA	10μA	5μA	1.5μA
Accuracy ※	±(0.5% of rdg. + 8 digit)					
Temperature coefficient	±(0.05% of rdg. + 0.8 digit)/°C					
Open terminal voltage	Peak 20mV or less (with ON/OFF function)					

※Accuracy : Defined at 23°C±5°C, 45~75%RH
 For the accuracy of MEDIUM sampling rate, a 3 digit is to be added.

■Resistance measurement (At FAST sampling)

■ Resistance measurement (At 1 A/S1 sampling)						
Measuring range	30m Ω	300m Ω	3 Ω	30 Ω	300 Ω	3k Ω
Resolution	10 μ Ω	100 μ Ω	1m Ω	10m Ω	100m Ω	1 Ω
Measuring current	7.4mA	1mA	100 μ A	10 μ A	5 μ A	1.5 μ A
Accuracy ※	Note-1	±(0.5% of rdg. + 6 digit)				
Temperature coefficient	Note-2	±(0.05% of rdg. + 0.6 digit)/°C				
Open terminal voltage	Peak 20mV or less (with ON/OFF function)					

Note-1 : ±(0.5% of rdg. + 8 digit)
 Note-2 : ±(0.05% of rdg. + 0.8 digit)/°C
 ※Accuracy : Defined at 23°C±5°C, 45~75%RH

■Voltage measurement (At SLOW, MEDIUM and FAST sampling)

Measuring range	±5V	±50V
Resolution	100μV	1mV
Accuracy ※	±(0.05% of rdg. + 5 digit)	
Temperature coefficient	±(0.005% of rdg. + 0.5 digit)/°C	

※Accuracy : Defined at 23°C±5°C, 45~75%RH
 ※For the accuracy of MEDIUM sampling rate, a 3 digit is to be added.
 ※For the accuracy of FAST sampling rate, a 5 digit is to be added.


9.3 ●General specifications

Measuring system	: AC 4 terminals system.
A/D working system	: Δ - Σ system.
Tolerable max. voltage to apply	: 60V DC for all the ranges.
Measuring frequency	: AC 1kHz \pm 0.2Hz.
Lead wire resistance	: Between SOURCE Hi – SOURCE Lo 0.4 Ω or less.
Display	: Green LED (character height 14.2mm). Resistance measurement : 35000 (3500 at the sampling rate F) Voltage measurement : 50000 (5000 at the sampling rate F, with polarity indication)
Over-range display	: With zero-suppress function. UUUUUU
Display mode	: Resistance, resistance comparator setting. Voltage, voltage comparator setting. Resistance, voltage.
Sampling rate	: 50Hz 60Hz SLOW : 1.56 times/sec. 1.88 times/sec. MEDIUM : 6.25 times/sec. 7.52 times/sec. FAST : 50 times/sec. 60 times/sec.
Response speed	: SLOW : approx. 1.92s approx. 1.60s MEDIUM : approx. 800ms approx. 667ms FAST : approx. 100ms approx. 84ms
Analog output	: Analog signal to the resistance value is output. Output Full scale 3V, output impedance 1k Ω or less. (With zero and max. adjustment volumes) Output voltage 0~3.000V with digital display 0~30000 (3000) digits. Conversion system D/A conversion system. Output accuracy Accuracy of resistance measurement \pm 0.2%F.S. Note: During the ratio display, the measured resistance value is output. During the setting of standard resistance value in the ratio display function, the output is retained.
Insulation resistance	: Terminal blocks in a lump / Housing 500VDC, 50M Ω or more
Withstanding voltage	: Terminal blocks in a lump / Housing 1500VAC for 1 minute Power source / Housing 1500VAC for 1 minute Measuring terminals / Output terminals 500VAC for 1 minute
Parameter retention	: The content of the setting for the function, range, value etc. set by key are retained by EEPROM even if the power is turned OFF.
Supply voltage	: 100~240VAC 50/60Hz
Range of supply voltage	: 90~250VAC
Power consumption	: Approx. 17VA at the 100VAC input. Approx. 21VA at the 200VAC input.
Working ambient temperature	: 0~50°C
Storage temperature	: -20~70°C
Weight	: Approx. 1 kg.
Accessories	: Power supply fuse: : 1 piece (Spare fuse: Mounted inside the power supply connector) Power supply cord with 3P \rightarrow 2P converter : 1 piece Connector for control input : 1 piece Instruction manual : 1 copy

9.4 ●Table of initial setting (at delivery from factor)

Measuring range	3 Ω
Memory 1~30	Resistance measurement, 3 Ω range
Comparator	HI SET: 3.0000 Ω , LO SET: 0.0000 Ω
Ratio display function	$\pm \Delta\%$: 010.0%
Key-lock	OFF
Buzzer	OFF setting, sound volume 5
Zero adjustment	OFF
Power source frequency setting	60Hz
Voltage limiter setting	ON

9.5 ●External dimensions



9.6 ●Option

- For the model 3566, the following interfaces are prepared.
For the handling of each interface, please refer to the instruction manual of respective interface.
 - GP-IB interface board : Model 5811-01A (Discontinued September 2014)
 - BCD data output board (TTL) : Model 5811-03A
 - BCD data output board (open collector) : Model 5811-04A
 - RS-232C interface board : Model 5811-05A
 - RS-485 interface board : Model 5811-06A
- Others
 - Kelvin clip : 5811-21C
 - Lead wire for resistance calibration : 5811-51
 - Clip type lead : 5811-22
 - Pin type lead : 5811-23A
 - Panel-mount bracket : 5811-31

10. Maintenance and calibration

10.1 ●Cleaning

In order to remove the dirt from this instrument, wipe lightly by a soft cloth with small amount of water and small amount of mild neutral detergent. Do not use detergent containing solvents like benzene, alcohol, paint thinner etc. It may cause deformation and decoloration.

10.2 ●Problem solving

In order to solve the problem, check the description in “When you think that there is a breakdown” and contact the nearest dealer or nearest sales office.

When breakdown goods are to be returned

The goods are to be packed so that it does not get damaged during transportation and write and attach the breakdown description as well. There is no guarantee for the damage during transportation.

When you think that there is a breakdown

Conditions	Confirmation	Countermeasure
Power lamp is not turned on and there is no display even when the power switches turned on.	Check if the power cord is unplugged.	Plug in the power cord.
	Check if the power fuse is blown out.	Change the spare fuse and turn on the power supply after disconnecting the input output cables.
Cannot operate the keys.	Is it in the key lock state?	Release the key lock.
	ONLINE is displayed and is it in external control state?	Turn off the ONLINE.
Display value differs largely with respect to the resistance being measured	0. ADJ is displayed and is zero adjustment turned ON?	Turn OFF the zero adjustment.
Measurement display does not change.	Is sampling display of S, M, F blinking? When the sampling display is not blinking the display is not renewed.	When HOLD is ON with remote control, turn it OFF. When HOLD is ON with communication, turn it OFF.
Error display		Refer error display table.

10.3 ●Calibration

To maintain the accuracy for the long term, it is recommended to calibrate about every one year. For calibration, request the place where it is purchased or our sales office. However, in case some fixed time has elapsed after purchase or the production of the parts have stopped or has exceeded the guarantee time, repair and the calibration may be declined.

MEMO

Tsuruga Electric Corporation

Osaka Sale office / Overseas Trade Department

Taiyo Seimei Osakaminami Bld. 5F

1-10-6, Abikohigashi, Sumiyoshi-ku, Osaka, Japan, 558-0013

Tel: + 81-(0)6-4703-3874 / Fax: + 81-(0)6-4703-3875

E-mail: ft.info@tsuruga.co.jp

Yokohama Office

1-29-15, Shinyokohama, Kohoku-ku, Yokohama, Kanagawa, Japan, 222-0033

Tokyo Office

5-25-16, Higashigotanda, Shinagawa-ku, Tokyo, Japan, 141-0022

Nagoya Office

Sun Park Higashi Betsuin Bld. 2F

5-19, Oicho, Naka-ku, Nagoya, Aichi, Japan, 460-0015

Osaka Plant

1-3-23, Minami Sumiyoshi, Sumiyoshi-ku, Osaka, Japan, 558-0041

Shiga Plant

122, Kawasaki-Cho, Nagahama, Shiga, Japan, 526-0846

Osaka Headquarters

1-3-23, Minamisumiyoshi, Sumiyoshi-ku, Osaka, Japan, 558-0041

www.tsuruga.co.jp

Instruction Manual
Interface of BCD Data Output

MODEL 5811-03A,04A
(for Model 3566)

I-01548

Contents

	Page
1.Specifications of BCD data input and output	3
1.1 Model 5811-03A (3566-03)	3
1.2 Model 5811-04B (3566-04)	3
2.Arrangement of connector pins	4
3.Explanation of input and output signals	5
3.1 Output signal	5
3.1.1 Measurement data output: 1, 2, 4, 8 ($\times 10^0 \sim \times 10^4$).....	5
3.1.2 Unit output: UNIT	5
3.1.3 Decimal point output: DP1~DP4	5
3.1.4 Polarity output: POL	5
3.1.5 Over-range output: OVER	5
3.1.6 Strobe output: STROBE	5
3.2 Input signal	6
3.2.1 Data enable: OUTPUT ENABLE	6
3.2.2 External hold input: HOLD.	6
3.2.3 Data select input: SEL	6
3.3.4 External control input: INT/EXT.	7
3.3.5 Function input: FUNCTION	7
3.3.6 Range input: RANGE	7
4.Operation	8
4.1 Resistance measurement	8
4.2 Ratio display	8
5.Timing chart	8
5.1 Data output	8
5.2 Timing chart for changeover of function	9

With use of the BCD output board, the measurement data of the model 3566 can be output, and also the measuring functions and measuring range can be externally controlled.

⚠ CAUTION

- Connect or disconnect the connector after turning off the power of instruments.
- Do not short-circuit the output or apply the voltage.

1. Specifications of BCD data input and output


1.1 ●Model 5811-03A (3566-03)

BCD data is output by TTL level.

Output system: BCD parallel code, positive logic


Outputs “L” level with logic “0”, and “H” level with logic “1”.

●Input



Input level: $I_{IL} \leq -1\text{mA}$
 “L”=0.8V or less
 “H”=3.5~5V

●Output



Output level: TTL level
 $F_o=2$


1.2 ●Model 5811-04A (3566-04)

BCD data is output by open collector.

Output system: BCD parallel code


Outputs “OFF” with logic “0”, and “ON” with logic “1”.

●Input




Input level: $I_{IL} \leq -1\text{mA}$
 “L”=0.8V or less
 “H”=3.5~5V

●Output



Output capacity: 30VDC, 30mA

2. Arrangement of connector pins



Signal name		Pin No.		Signal name	
UNIT	0	1	26	4	UNIT
	1	2	27	5	
	2	3	28	6	
	3	4	29	7	
$\times 10^0$	1	5	30	1	$\times 10^1$
	2	6	31	2	
	4	7	32	4	
	8	8	33	8	
$\times 10^2$	1	9	34	1	$\times 10^3$
	2	10	35	2	
	4	11	36	4	
	8	12	37	8	
$\times 10^4$	1	13	38	POL	
OUTPUT ENABLE		14	39	OVER	
HOLD		15	40	STROBE	
$\times 10^4$	4	16	41	1	SEL
DP2		17	42	2	
DP3		18	43	4	
DP4		19	44	2	$\times 10^4$
FUNCTION	1	20	45	1	RANGE
	2	21	46	2	
	4	22	47	4	
	8	23	48	NC	
INT./EXT.		24	49		
DATA COM		25	50	DATA COM	

Connector: (Anphenol) 57-30500

Note: Do not use the NC pins as they are connected to the internal circuit.

3. Explanation of input and output signals

3.1 ●Output signal

3.1.1 Measurement data output: 1, 2, 4, 8 ($\times 10^0 \sim \times 10^4$)

The measurement data is output by parallel BCD code.

Note: When the $\times 10^0$ digit is blank display (when the sampling rate is FAST and in the ratio measurement), 0 is output.

3.1.2 Unit output: UNIT

The output of the unit is output by 8 bit code.

Table of unit code

Unit	UNIT							
	7	6	5	4	3	2	1	0
m Ω	1	0	0	1	1	0	0	0
Ω	1	1	1	1	1	1	1	0
k Ω	0	1	1	0	0	1	0	1
%	1	1	1	0	0	0	0	0
V	1	1	1	1	0	1	1	0

3.1.3 Decimal point output: DP2~DP4

Decimal point corresponding with measurement range is output with code.

Table of output code

Display		Output		
		DP4	DP3	DP2
350.00 (350.0□)		1	1	0
35.000 (35.00□)	50.000 (50.00□)	1	0	1
3.5000 (3.500□)	5.0000 (5.000□)	0	1	1

3.1.4 Polarity output: POL

“1” is output at positive (plus) polarity.

“0” is output at negative (minus) polarity.

3.1.5 Over-range output: OVER

Error 0 : When the measurement data has exceeded 35000 (3500□) or the voltage measurement data has exceeded 50000 (5000□), OVER becomes “1” and the data 00000 is output.


Error 3 : When the data select code is other than the designated ones, OVER becomes “1” and the data 00003 is output.

3.1.6 Strobe output: $\overline{\text{STROBE}}$

At the renewal of data, the “L” pulse is output as the following figure shows.

Transact the data taking the rising point of this pulse.

Note: When the tester is of open collector, ON is output.



Sampling rate	t
FAST	Approx. 1ms
SLOW, MEDIUM	Approx. 10ms

3.2 ●Input signal

3.2.1 Data enable: OUTPUT ENABLE

At “L” level, all the output except $\overline{\text{STROBE}}$ become “high impedance” status.

3.2.2 External hold input: $\overline{\text{HOLD}}$

The sampling is made with “H” level and the measurement data is output each time.
The sampling is stopped with “L” level and the BCD data and displayed value are held.
During the hold, the switch operation on the front panel is not accepted.

3.2.3 Data select input: SEL

With the input of select code, the measurement data other than the displayed data can be output. When doing the data select, make the display and the data hold status in advance.

Note-1: If the data select is done without holding, the displayed value and the data output may sometimes be different.

Note-2: The display does not change even if the data select is done.

Data select procedure

Make an input of the select code in the table and select the necessary data.

Table of data output and select code


Select code	4	2	1	4	2	1	4	2	1	4	2	1	4	2	1	4	2	1	4	2	1	4	2	1
Function	L	L	L	L	L	H	L	H	L	L	H	H	H	L	L	H	L	H	H	H	L	H	H	H
At resistance measurement	VOLT			OHM			OHM			OHM			OHM			OHM			OHM			OHM		
At ratio display	VOLT			Rs			Rx			Err3			Err3			Err3			Err3			X		

Note-1:

Function	Symbol	Content
At resistance measurement	OHM VOLT	Resistance value Voltage value
At ratio display	Rs Rx X VOLT	Standard resistance value Measured resistance value Ratio Voltage value

Note-2: When the select code is other than specified input, the signal “Error 3” is output.
(Err3: The over-range output is “1” and the data output is 00003.)

○Timing chart of the data select



3.2.4 External control input: INT./EXT.

By making “L” level, the following operations can be externally controlled.
In this case, the operation by the switches on the front panel is disabled.

- Selection of function
- Selection of range

Note:

- The external control is not possible during the hold.
- No selection of the function or range is possible while the remote operation of the memory mode.

3.2.5 Function input: FUNCTION

By designation of the function code, each function can be externally controlled.
When making an input of the function code, make the INT./EXT. input “L” level in advance.

Function	8	4	2	1
Resistance measurement	H	L	L	H
Ratio display	L	H	H	H


Note: The setting other than the above is invalid.

3.2.6 Range input: RANGE

By making an input of a range code, the resistance range can be externally selected.
When making an input of the range, make the INT./EXT. input “L” level in advance.

RANGE			Range	
4	2	1		
L	L	L	Resistance range	Auto-range
L	L	H	Resistance range	30m Ω
L	H	L	Resistance range	300m Ω
L	H	H	Resistance range	3 Ω
H	L	L	Resistance range	30 Ω
H	L	H	Resistance range	300 Ω
H	H	L	Resistance range	3k Ω

○Timing chart of the changeover of range



4. Operation

4.1 ●Resistance measurement

Please refer to the article 5.1 of the tester main unit.

- ① Make the external control input (INT./EXT.) “L” level.
- ② Input the resistance measurement code to the function (FUNCTION).
- ③ Input the range code to the range (RANGE) and select the resistance range.
- ④ Start the measurement.


4.2 ●Ratio display

Please refer to the article 5.5 of the tester main unit.

- ① Make the external control input (INT./EXT.) “L” level.
Note: When setting the numeral of the standard resistance value, make the INT./EXT. “H” level and set with the switch on the front panel.
- ② Select the resistance range with the range (RANGE).
- ③ Input the OHM RATIO or T.C RATIO code to the function (FUNCTION).
OHM RATIO : Displays the ratio in the resistance measurement.
T.C RATIO : Displays the ratio in the temperature compensation.
- ④ Start the measurement.

5. Timing chart

5.1 ●Data output




Tsh: $T_s + 3ms$

T_s : Sampling time

Power source frequency	50Hz	60Hz
Sampling rate setting		
F	13~36ms	12~28ms
M	90~170ms	70~143ms
S	570~650ms	485~540ms

//// section High impedance

5.2 ●Timing chart for changeover of function



Contact Information

Tsuruga Electrical Corporation
Osaka Sale office / Overseas Trade Department
Taiyo Seimei Osakaminami Building 5F
1-10-6, Abikohigashi, Sumiyoshi-ku, Osaka, Japan, 558-0013
Tel: + 81-(0)6-4703-3874 / Fax: + 81-(0)6-4703-3875
E-mail: ft.info@tsuruga.co.jp

Instruction Manual
Interface of BCD Data Output

MODEL 5811-03D,04D
(for Model 3568)

I-01680

Contents

1. Specifications of BCD data input & output	2
1.1 MODEL 5811-03D (3568-03)	2
1.2 MODEL 5811-04 D(3568-04)	2
2. Arrangement of connector pins	3
3. Explanation of input/output signals	4
3.1 Output signals	4
3.1.1 Measuring data output : 1, 2, 4, 8 ($\times 10^0 \sim \times 10^4$)	4
3.1.2 Unit output : UNIT	4
3.1.3 Decimal point output : DP1~DP4	4
3.1.4 Polarity output : POL	4
3.1.5 Over-range output : OVER	4
3.1.6 Strobe output : $\overline{\text{STROBE}}$	4
3.2 Input signals	5
3.2.1 Data enable : OUTPUT ENABLE	5
3.2.2 Remote hold input : $\overline{\text{HOLD}}$	5
3.2.3 Data selection input : SEL	5
3.2.4 Remote control input : INT/ $\overline{\text{EXT.}}$	6
3.2.5 Input of function : FUNCTION	6
3.2.6 Range input : RANGE	7
4. Operation	8
4.1 Resistance measurement	8
4.2 Temperature measurement	8
4.3 Temperature compensation	8
4.4 Ratio display	8
4.5 Temperature conversion	9
5. Timing chart	10
5.1 Data output	10
5.2 Timing chart for switching-over of function	10

With BCD data output board, this interface can perform the remote control of measuring function and measuring range as well as output measuring data of the model 3568.

! CAUTION

**Switch OFF the power of the main unit and pull out the power cord plug.
Do not short-circuit or apply voltage to output.**


1. Specifications of BCD data input & output

1.1 MODEL 5811-03D (3568-03)


BCD data is output by TTL level.

Output system : Parallel BCD code, positive logic.

“L” level is output by logic “0”, and “H” level by logic “1”.



Input level : I_{IL} -1mA
“L” = 0.8V or less
“H” = 3.5 ~ 5V




Output level : TTL level
Fo = 2

1.2 MODEL 5811-04D (3568-04)


BCD data is output by open collector

Output system : Parallel BCD code.

“OFF” is output by logic “0”, and “ON” by logic “1”.




Input level : I_{IL} -1mA
“L” = 0.8V or less
“H” = 3.5 ~ 5V



Output capacity : DC30V, 30mA

2. Arrangement of connector pins



Signal name		Pin No.		Signal name	
UNIT	0	1	26	4	UNIT
	1	2	27	5	
	2	3	28	6	
	3	4	29	7	
$\times 10^0$	1	5	30	1	$\times 10^1$
	2	6	31	2	
	4	7	32	4	
	8	8	33	8	
$\times 10^2$	1	9	34	1	$\times 10^3$
	2	10	35	2	
	4	11	36	4	
	8	12	37	8	
$\times 10^4$	1	13	38	POL	
OUTPUT ENABLE		14	39	OVER	
HOLD		15	40	STROBE	
DP1		16	41	1	SEL
DP2		17	42	2	
DP3		18	43	4	
DP4		19	44	2	$\times 10^4$
FUNCTION	1	20	45	1	RANGE
	2	21	46	2	
	4	22	47	4	
	8	23	48	NC	
INT. / EXT.		24	49		
DATA COM		25	50	DATA COM	

Connector: (Anphenol) 57-30500

Note: Do not use NC pin as it is connected to the internal circuit.

3. Explanation of input/output signals

3.1 Output signals

3.1.1 Measuring data output : 1, 2, 4, 8 ($\times 10^0 \sim \times 10^4$)

Measured data is output with parallel BCD code.

3.1.2 Unit output : UNIT

“Unit” data is output with 8 bit code.

Table of unit code:

Unit	UNIT							
	7	6	5	4	3	2	1	0
m	1	0	0	1	1	0	0	0
	1	1	1	1	1	1	1	0
k	0	1	1	0	0	1	0	1
°C	1	0	1	1	0	0	0	1
%	1	1	1	0	0	0	0	0

3.1.3 Decimal point output : DP1~DP4

Position of decimal point is output with 4 bit code.

Table of output code:

Display	Output			
	DP4	DP3	DP2	DP1
3 5 0 . 0 0	1	1	0	1
3 5 . 0 0 0	1	0	1	1
3 . 5 0 0 0	0	1	1	1

3.1.4 Polarity output : POL

“1” is output for plus polarity.

“0” is output for minus polarity.

3.1.5 Over-range output : OVER

Error 0 : When the data exceeded 35000 (3500) or the measured temperature exceeded the measuring range in temperature measurement, OVER becomes “1” and the data 00000 is output.

Error 1 : When the data exceeded the temperature measuring range in temperature compensation function and temperature conversion function, OVER becomes “1” and the data 00001 is output.

Error 2 : When the calculation is faulty, OVER becomes “1” and the data 00002 is output.


Error 3 : When the data selection input is out of the designated codes, OVER becomes “1” and the data 00003 is output.

3.1.6 Strobe output : $\overline{\text{STROBE}}$

At renewal of data, “L” pulse is output as the figure below shows.

Catching this rising point, transact the data.

Note: ON is output when the specifications are provided with the open collector output.



Sampling rate	t
SLOW, FAST	Approx. 10ms

3.2 Input signals

3.2.1 Data enable : OUTPUT ENABLE

All the output except $\overline{\text{STROBE}}$ become “high impedance” status at “L” level.

3.2.2 Remote hold input : $\overline{\text{HOLD}}$

At “H” level, sampling is done and the measuring data is sequentially output.

At “L” level, sampling is stopped and, the BCD data and display value are held.

During the hold, switch operation on the front panel is not accepted.

3.2.3 Data selection input : SEL

By making an input of selection code, in measurement of temperature compensation, temperature conversion or ratio display, the measuring data can also be output in addition to the displayed data.

When making the data selection, do it after getting the display value and data in hold status.

Note 1: If it is done without holding, the display value and output data may be different.

Note 2: Display remains unchanged even if the status becomes data selection status.

Example: The display value, during the temperature compensation function in operation, is the conversion value (R_T).

If the data output of ambient temperature (t) or resistance value (R_t) at the ambient temperature t is necessary, select the output data by making an input of selection code.

How-to-select:

Make an input of selection code in the table and select the necessary data.

Table of data output & selection code


Selection code		4	2	1	4	2	1	4	2	1	4	2	1	4	2	1	4	2	1	4	2	1	4	2	1
		L	L	L	L	L	H	L	H	L	L	H	H	H	L	L	H	L	H	H	H	L	H	H	H
Function		OHM			OHM			OHM			OHM			OHM			OHM			OHM			OHM		
At resistance measurement		OHM			OHM			OHM			OHM			OHM			OHM			OHM			OHM		
At temperature measurement		TEMP			TEMP			TEMP			TEMP			TEMP			TEMP			TEMP			TEMP		
At temperature compensation		Err3			R_t			t			Err3			Err3			Err3			Err3			R_T		
At ratio display		Err3			R_S			R_X			Err3			Err3			Err3			Err3			X		
At temperature conversion	T_1 measurement	Err3			T_1			R_1			Err3			Err3			Err3			Err3			R_1		
	T_2 measurement	Err3			Err3			Err3			T_2			R_2			Err3			Ter			R_2		
	TE conversion	Err3			T_1			R_1			T_2			R_2			Err3			Ter			TE		

Note 1:

Function	Display	Contents
At resistance measurement	OHM	Resistance value
At temperature measurement	TEMP	Temperature
At temperature compensation	R_t T R_T	Resistance value at ambient temperature () Ambient temperature Compensation resistance
At ratio display	R_S R_X X	Standard resistance value Measuring resistance value Ratio
At temperature conversion	T_1 R_1 T_2 R_2 Ter Te	Ambient temperature at the start of the test Coil resistance at temperature T_1 Ambient temperature at the end of the test Coil resistance at temperature T_2 Increased temperature of coil by TE calculation is sequentially output. Temperature increase of coil at switching to Te

Note 2: When the data selection input is out of the designated codes, “Error 3” signal is output.
(Err3: OVER signal becomes “1” and the data 00003 is output.)

Timing chart for data selection



3.2.4 Remote control input : INT. / $\overline{\text{EXT}}$.

By making “L” level, the following operations can be remote-controlled.

In this case, the switch operation from the front panel is disabled.

Selection of function

Selection of range

Note: During the hold, no control is possible.

During the remote-controlled memory mode, no function or no range can be selected.

3.2.5 Input of function : FUNCTION

By designating a function code, each function can be remote-controlled. When inputting the function code, do it after setting INT. / $\overline{\text{EXT}}$ input to “L” level.

Function		8	4	2	1
Resistance measurement		H	L	L	H
Temperature measurement		H	L	L	L
Temperature compensation		L	H	L	L
Ratio display	OHM RATIO	L	H	H	H
	T. C RATIO	L	H	L	H
Temperature conversion	Te CLR	L	L	H	H
	T ₁	L	L	H	L
	T ₂	L	L	L	H
	Te	L	L	L	L


Note: Setting other than the above is ineffective.

3.2.6 Range input : RANGE

By making an input of range code, it is possible to remotely select a resistance.
When inputting the range code, do it after setting INT. / EXT. input to “L” level.

RANGE			Range
4	2	1	
L	L	L	Resistance measurement Auto range
L	L	H	Resistance measurement 300m
L	H	L	Resistance measurement 3
L	H	H	Resistance measurement 30
H	L	L	Resistance measurement 300
H	L	H	Resistance measurement 3k
H	H	L	Resistance measurement 30k
H	H	H	Resistance measurement 300k

Timing chart for switching-over of range



4. Operation

4.1 Resistance measurement

Refer to the article 5.1 of this manual.

Make the remote control input (INT. / EXT.) “L” level.

Input a resistance measurement code to the function (FUNCTION).

Input a range code to the range (RANGE) and select a resistance range.

Start measurement.

4.2 Temperature measurement

Refer to the article 5.2 of this manual.

Make the remote control input (INT. / EXT.) “L” level.

Input a temperature measurement code to the function (FUNCTION).

Start measurement.

4.3 Temperature compensation

Refer to the article 5.3 of this manual.

Make the remote control input (INT. / EXT.) “L” level.

Note 1: Setting of standard temperature and temperature coefficient:

Make the remote control input (INT. / EXT.) “H” level, and set with the switch on the front panel.

Select a resistance range with the range (RANGE).

Input a temperature compensation code to the function (FUNCTION).

Start measurement.

4.4 Ratio display

Refer to the article 5.5 of this manual.

Make the remote control input (INT. / EXT.) “L” level.

Note : When making numeral setting of standard resistance value:

Make the remote control input (INT. / EXT.) “H” level, and set with the switch on the front panel.

Select a resistance range with the range (RANGE).

Input OHM RATIO or T.C RATIO code to the function (FUNCTION).

OHM RATIO : Display of ratio at resistance measurement

T.C RATIO : Display of ratio at temperature compensation

Start measurement.

4.5 Temperature conversion

Refer to the article 5.4 of this manual.

Make the remote control input (INT. / $\overline{\text{EXT.}}$) "L" level.

Input the Te CLR code. (It clears internal memory.)

"T.E CLR" is displayed.

Connect a test sample to measuring input.

Input the T₁ code.

"T.E T1" is displayed.

Input the T₂ code.

T₁ and R₁ at input are memorized.

"T.E T2" is displayed.

Disconnect the measuring input and make a conductance test.

After finishing the conductance test, connect the test sample to the measuring input.

Input the T.E code.

"T.E END" is displayed.


Temperature increase at input is memorized as Te.

Read-out of each data: After the finish of temperature conversion, the data T₁, T₂, R₁, R₂ and TE of each channel is output.

Note 1: Perform the measurement separately from the conductance test. If the test sample is in the condition being conducted, the measurement can not be made.


Note 2: Zero-adjustment function can not be used.

Performance




5. Timing chart

5.1 Data output



5.2 Timing chart for switching-over of function



Contact Information

Name : Tsuruga Electric Corporation
Address : 1-3-23 Minami-Sumiyoshi, Sumiyoshi-ku, Osaka-shi
558-0041 Japan

Instruction Manual
Interface of RS-232C

MODEL 5811-05A
(for Model 3566)

I-01549

Contents

Page

1.Specifications	3
2.Connection	3
2.1 Connector and signal	3
2.2 Xon/Xoff control	3
2.3 Connection cable	4
2.4 Setting of communication	4
2.5 ONLINE switch	4
3.Explanation of communication	5
4.Explanation of command	6
4.1 ●Program data	6
4.2 ●Detail of command data	7
4.2.1 ONLINE= (setting of online)	7
4.2.2 ONLINE? (read-out of online)	7
4.2.3 BUZZ= (setting of buzzer)	8
4.2.4 BUZZ? (read-out of buzzer data)	8
4.2.5 MODE= (changeover of mode)	9
4.2.6 MODE? (read-out of mode)	9
4.2.7 MEM=CALL (call-up of memory)	9
4.2.8 MEM No? (read-out of memory setting data)	10
4.2.9 MEM= (setting of memory data)	11
4.2.10 COMPR=, COMPV= (setting of comparator)	12
4.2.11 COMPR?, COMPV? (read-out of comparator data)	12
4.2.12 DATA? (read-out of measurement data)	13
4.2.13 FUNCTION= (measuring function)	14
4.2.14 FUNC? (read-out of function data)	14
4.2.15 HOLD= (setting of hold)	15
4.2.16 HOLD? (read-out of hold status)	15
4.2.17 RANGE= (setting of measuring range)	16
4.2.18 RANGE? (read-out of measuring range)	16
4.2.19 RATIOSTD= (setting of standard ratio value)	17
4.2.20 RATIOSTD? (read-out of standard ratio value data)	17
4.2.21 RST= (judgement reset)	18
4.2.22 RST? (read-out of judgement reset status)	18
4.2.23 SAMPLING= (setting of sampling rate)	19
4.2.24 SAMPLING? (read-out of sampling rate)	19
4.2.25 ZEROADJ= (setting of zero adjustment)	20
4.2.26 ZEROADJ? (read-out of zero adjustment status)	20
4.2.27 VIEW= (setting of display mode)	21
4.2.28 VIEW? (read-out of display mode)	21

1. Specifications


Table 1.1

Transmission system	Start-stop synchronous duplex transmission
Transmission speed	9600, 4800, 2400bps (Set to 9600bps at delivery from factory)
Data bit length	8 bit
Stop bit	1 bit
Parity bit	Nil, even number, odd number (Set to Nil at delivery from factory)
Delimiter	LF (0AH)
Xon/Xoff	Controllable (Xon at delivery from factory)
Connector	Sub-D 9 pin (male)


2. Connection

2.1 Connector and signal

Meter connector D-sub9pin



Attached connector: D-sub9pin plug type



XM2D-0901 (OMRON)


Pin No.	Meter signal JIS (RS-232C)	Direction	Name
			Not in use
	RD (RXD)	Input	Receiving data
	SD (TXD)	Output	Transmission data
			Not in use
	SG (GND)		Ground for signal
			Not in use
	RS (RTS)	Output	Request for transmission
	CS (CTS)	Input	Transmittable
			Not in use

2.2 Xon/Xoff control

Soft handshake: The transmission is stopped when Xoff is received and re-started when Xon is received.
(Xon: 11H (ASCII), Xoff: 13H (ASCII))

2.3 Connection cable


No hardware handshake



2.4 Setting of communication

Setting of the communication speed and parity bit can be done by the dip switch on the rear panel.

Arrangement of dip switch on the rear panel.



Setting of communication speed

Set the speed with the dip switch 1, 2 and 3.

Communication speed	1	2	3
2400bps		×	×
4800bps	×		×
9600bps	×	×	

Set the switch marked ☐ to ON

Set the switch marked ☒ to OFF

Setting of parity bit

Set the parity with the dip switch 4 and 5.

Parity bit	4	5
Even number		×
Odd number	×	
Nil	×	×

Set the switch marked ☐ to ON

Set the switch marked ☒ to OFF

Note: Make the setting of the dip switch with the power supply switched OFF.

2.5 ONLINE switch

By setting the dip switch No.8 on the rear panel to ON side, the ONLINE on the front panel is lit up, and it is enabled to do a remote control by RS-232C and to read-out the data setting.


The control functions in ONLINE are as follows.

● Setting of each setting parameter is possible.

Note:

- In the ONLINE status, the key operation from the front panel is not allowed.
- Read-out of the measurement data and working status is possible both in OFFLINE and ONLINE.

3. Explanation of communication



Response frame:

When the effective setting command is received, the content of setting is returned.

When the effective output command is received, the designated data is output.

When the ineffective command is received, the "Command Error" is returned.

Example: In case of effective command: FUNCTION=OHM,

Response: FUNCTION=OHM

In case of ineffective command: FUNCTION=MACHIGAI,



Response: Command Error

4. Explanation of command

4.1 Program data

JIS punctuation code is used for the command data.

Example:

RANGE=30mOHM  

Command Delimiter


1. Command Command to control the 3566.
2. Delimiter Code (delimiter) to inform the 3566 of the finish of transmission data block.
 judged as delimiter when received the (OAH).

Table of character code

	0	1	2	3	4	5	6	7
0			SP	0	@	P	`	p
1			!	1	A	Q	a	q
2			”	2	B	R	b	r
3			#	3	C	S	c	s
4			\$	4	D	T	d	t
5			%	5	E	U	e	u
6			&	6	F	V	f	v
7			'	7	G	W	g	w
8			(8	H	X	h	x
9)	9	I	Y	i	y
A			•	:	J	Z	j	z
B			+	;	K	[k	{
C			,	<	L	¥	l	
D			-	=	M]	m	}
E			.	>	N	^	n	~
F			/	?	O	_	o	

Blank code is undefined.

4.2 Detail of command data ---

4.2.1 ONLINE= (setting of online)

Function	The settings and to do or not to the control through RS-232C is set.
Structure	ONLINE= <input type="text" value="ON/OFF"/>
<input type="text" value="ON/OFF"/>	: The setting and control through RS-232C is possible with "ON". The setting and control through RS-232C is not possible with "OFF".
Note:	The setting is not possible when the ONLINE is made by the dip switch on the rear.

4.2.2 ONLINE? (read-out of online)

Function	The settings of online is read out.
Structure	ONLINE?
Transmission	
ONLINE?	
Response	
ONLINE OFF	

4.2.3 BUZZ= (setting of buzzer)

Function	Make the setting of buzzer for OFF, GO, HI, LO, HILO, PASS, FAIL, GOOD and NG.
Structure	BUZZ=[OFF/GO/HI/LO/HILO/PASS/FAIL/GOOD/NG], [Data] BUZZ= : Buzzer setting command [OFF/GO/HI/LO/HILO/PASS/FAIL/GOOD/NG] : “OFF” designates the buzzer OFF. “GO” designates the buzzer at GO. “HI” designates the buzzer at HI. “LO” designates the buzzer at LO. “HILO” designates the buzzer at HI or LO. “PASS” designates the PASS buzzer. “FAIL” designates the FAIL buzzer. “GOOD” designates the buzzer at GO and PASS buzzer. “NG” designates the buzzer at HI, LO or FAIL buzzer. Note: Either one of the buzzer setting is possible. [Data] : Designates the buzzer sound volume. Sound volume can be set in 9 steps “01” ~ “10”. Note: When the setting is buzzer OFF, the designation for buzzer sound volume is disregarded.

Transmission

Set GOOD buzzer sound level to 3.

BUZZ=GO, 03

4.2.4 BUZZ? (read-out of buzzer data)

Function	The mode and the sound volume of buzzer are read out.
Structure	BUZZ?
Transmission	BUZZ?
Response	BUZZ=GO, 03

The data of buzzer mode. (data length = 4)
The sound volume data 01 ~ 10. (data length = 2)

4.2.5 MODE= (changeover of mode)

Function	Changeover of memory mode, manual mode.
Structure	MODE=[Mode]
	MODE= : Mode changeover command
	[Mode] : “MEMORY” designates the memory mode. “MANUAL” designates the manual mode.

Transmission

Designate to the memory mode.

MODE=MEMORY

4.2.6 MODE? (read-out of mode)

Function	Read out the memory mode, manual mode.
Structure	MODE?

Transmission

MODE?

Response

MODE=MANUAL

Mode setting data (data length = 6).

4.2.7 MEM=CALL (call-up of memory)

Function	The memory designated by the No. is called up. Note: Make the setting after changing to the memory mode.
----------	---

Structure	MEM=CALL[No.]
	MEM= : Memory number setting command.
	[No.] : Designate the memory “01” ~ “30”.

Transmission

Designates to the memory No.01 and works afterwards as the memory No.01.

MEM=CALL01

Note: If it is not in the memory mode, “Not Control” is returned.

4.2.8 MEM [No.]? (read-out of memory setting data)

Function	Read out the memory data designated by the No. Note: Make the setting after changing to the memory mode.
----------	--

Structure	MEM [No.]?
-----------	------------

[No.] : Designate the memory "01" ~ "30".

Transmission

MEM01?

Response

MEM=01, OHM_ _ _ _ _ , OHM _ _ _ _ _ , 300mOHM, RH35. 000_OHM, RL100. 00_OHM
, 5V_ , VH+5. 0000V, VL-2. 0000V

Shows the memory number (data length = 2).

Shows the display mode (data length = 8).

Shows the resistance measurement function (data length = 10).

Shows the resistance measurement range (data length = 7).

Shows the HI data of resistance comparator (data length = 12).

Shows the LO data of resistance comparator (data length = 12).

Shows the voltage measurement range (data length = 3).

When the resistance range is set to AUTO, the voltage measurement also works in the auto-range.

The set value is output as response data.

Shows the HI data of voltage comparator. (data length = 10).

Shows the LO data of voltage comparator. (data length = 10).

4.2.9 MEM= (setting of memory data)

Function

Set the memory data.
Make the setting after changing to the memory mode.

Structure

MEM= [No.], [VIEW], [FUNC], [RANGE], RH [HI SET],
RL [LO SET], [VOLT], VH [HI SET], VL [LO SET]

MEM= : Data setting command of the memory.
[No.] : Designate the memory number "01" ~ "30".
[VIEW] : Display mode "OHM", "VOLT", "OHM-VOLT".
[FUNC] : Function table "OHM", "OHM-RATIO".
[RANGE] : Designates either one of the resistance range
"30mOHM", "300mOHM", "30OHM", "300OHM",
"3000OHM", "3kOHM".
RH [HI SET] : High limit value data of the resistance comparator.
(Adjustable range of numeral: 0~35000)
RL [LO SET] : Low limit value data of the resistance comparator.
(Adjustable range of numeral: 0~35000)
[VOLT] : Voltage range "5V", "50V".
VH [HI SET] : High limit value data of the voltage comparator.
(Adjustable range of numeral: ± 50000)
VL [LO SET] : Low limit value data of the voltage comparator.
(Adjustable range of numeral: ± 50000)

Note-1: RH [HI SET] and RL [LO SET] are to be set adding the unit and decimal point.

Example of setting: 35.000kOHM

Note-2: When the FUNC is RATIO, HI SET: Standard value,
LO SET: Deviation are to be set.

Example of setting: H100.000OHM, L10.0%

Note-3: VH [HI SET] and VL [LO SET] are to be set adding the unit and decimal point.

Example of setting: 45.000V

Transmission

MEM=01, OHM, OHM, 300mOHM, RH35.0000OHM, RL100.000OHM, 5V, VH5.0000V, VL2.0000V

MEM=01, OHM, OHM-RATIO, 300OHM, RH15.0000OHM, RL100.0%, 5V, VH5.0000V, VL2.0000V

Note: If it is not in the memory mode, "Not Control" is returned.

4.2.10 COMP=, COMPV= (setting of comparator)

Function	Set the high and low limit value and the unit of the comparator.		
Structure	COMP=RH	HI SET, RL	LO SET
	COMP=VH	HI SET, VL	LO SET

For resistance comparator
For voltage comparator

COMP= : Comparator setting command

HI SET : High limit set value of the comparator
(Adjustable range of numeral 0~35000)

LO SET : Low limit set value of the comparator
(Adjustable range of numeral 0~35000)

Note-1: HI SET and LO SET are to be set adding the unit and decimal point.

Example of setting: 35.000kOHM, 5.0000V

Note-2: Adjust the unit and decimal point of HI SET and LO SET to the same.

Transmission

Set the HI SET of resistance comparator to 2.0000k and the LO SET to 1.5000k .
COMP=RH2.0000kOHM, RL1.5000kOHM

Set the HI SET of voltage comparator to 15.000V and the LO SET to 2.000V.
COMPV=VH+15.000V, VL-02.000V

Note: The setting is not possible in the memory mode.
The setting of the resistance comparator is not possible when the measuring function is RATIO (ratio display).

4.2.11 COMP=?, COMPV? (read-out of comparator data)

Function	Read out the high and low limit value of the comparator.		
----------	--	--	--

Structure	COMP=?	Read-out of the resistance comparator
	COMPV=?	Read-out of the voltage comparator

Transmission

COMP=?

Response

COMP=RH3.0000kOHM, RL1.0000kOHM

Shows the data output of resistance comparator.

Shows the HI data of the comparator (data length = 12).

Shows the LO data of the comparator (data length = 12).

Note: The read-out is not possible when the resistance measurement function is RATIO (ratio display).

Transmission

COMPV=?

Response

COMPV=VH+5.0000V, VL-1.0000V

Shows the data output of comparator.

Shows the HI data of the comparator. (data length = 10).

Shows the LO data of the comparator. (data length = 10).

4.2.12 DATA? (read-out of measurement data)

Function	Read out the measurement data.
----------	--------------------------------

Structure	DATA?
-----------	-------

DATA? : Measurement data output command

Transmission

DATA?

Response

1. Resistance measurement

OHM=+199.99kOHM, R-JUDGE=HI LO, VOLT=+0.1234V, V-JUDGE=FAIL

Resistance measurement data (data length = 11)

Resistance judgement output (data length = 13)

Voltage measurement data (data length = 13)

Voltage judgement output (data length = 12)

2. Ratio measurement

RATIO=+0123.4%, Rs=1.0000_OHM, Rx=+1.2345_OHM, R-JUDGE=GO,

VOLT=+0.1234V, V-JUDGE=FAIL

Shows the ratio data (data length = 7)

Shows the resistance measurement data (data length = 13)

Shows the ratio standard resistance value (data length = 14)

Shows the resistance judgement output (data length = 13)

Shows the voltage measurement data (data length = 13)

Shows the voltage judgement output (data length = 12)

Note: R-JUDGE output

At GO : R-JUDGE=GO

At HI : R-JUDGE=HI

At LO : R-JUDGE=LO

At HI LO : R-JUDGE=HI LO

At No judgement output : R-JUDGE=NULL

At CC error : R-JUDGE=CC

(CC error means the SOURCE open.)

(At the CC error, the CC error is output regardless of the judgement result.)

V-JUDGE output

At good voltage judgement : V-JUDGE=PASS

At faulty voltage judgement : V-JUDGE=FAIL

At No judgement output : V-JUDGE=NULL

4.2.13 FUNCTION= (measuring function)

Function	Designate the measuring function.
Structure	FUNCTION= Function code FUNCTION= : Function setting command Function : “OHM” Resistance measurement, “OHM-RATIO” Ratio display.

Transmission

Set the measuring function to the resistance measurement.

FUNCTION=OHM
FUNCTION=OHM-RATIO

4.2.14 FUNC? (read-out of function data)

Function	Read out the type of measuring function.
Structure	FUNC? FUNC? : Measuring function output command

Transmission

FUNC?

Response

FUNCTION=OHM

Shows the function data output. (data length = 9)
Shows the measuring function data.

4.2.15 HOLD= (setting of hold)

Function	Set the start and cancellation of the hold.
Structure	HOLD= ON/OFF HOLD= : Hold setting command. ON/OFF : Stop the sampling and hold the data with “ON”. Designate the cancellation of hold with “OFF”.
Transmission	 Set the hold to ON. HOLD=ON

4.2.16 HOLD? (read-out of hold status)

Function	Read out the status of hold.
Structure	HOLD?
Transmission	 HOLD?
Response	 HOLD=ON_ Shows the hold data output. Shows the status data of the hold. (data length = 3)

4.2.17 RANGE= (setting of measuring range)

Function

Set the range of resistance measurement.

Note: No setting is possible in the temperature measurement.

Structure

RANGE=**Range**

RANGE= : Measuring range setting command

Range : For the resistance measurement, set the range among
30m ~ 3k .

To make the auto-range, set AUTO.

Table 4.1

Range code	Measuring range
30mOHM	30m
300mOHM	300m
3OHM	3
30OHM	30
300OHM	300
3kOHM	3k
AUTO	Auto-range

Transmission

Set the resistance measurement range to 30 .

RANGE=30OHM

4.2.18 RANGE? (read-out of measuring range)

Function

Read out the setting condition of the measuring range.

Structure

RANGE?

Transmission

RANGE?

Response

RANGE=3__kOHM

Shows the range data output.

Shows the data of setting condition of the range. (data length = 7)

4.2.19 RATIOSTD= (setting of standard ratio value)

Function

Set the standard value and deviation of the ratio display.

Note: The setting is not possible when the measuring function is other than the ratio display function.

Structure

RATIOSTD=

REF

,

$\pm \Delta$

RATIOSTD : Setting command of the ratio standard value.

REF

: Standard resistance value.

$\pm \Delta$

: \pm deviation data (00.0~199.9%)

Transmission

Set the 10.000 to the standard resistance value, and 20.0% to the deviation %.

RATIOSTD=10.000OHM, 20.0%

4.2.20 RATIOSTD? (read-out of standard ratio value)

Function

Read the data of ratio standard value.

Structure

RATIOSTD?

Transmission

RATIOSTD?

Response

RATIOSTD=10.000kOHM, 020.0%

Shows the data output of the ratio standard.

Shows the data of standard value. (data length = 10)

Shows the deviation data %. (data length = 6)

4.2.21 RST= (judgement reset)

Function	Make ON/OFF of reset for the comparator judgement. (Reset the comparator output and turn OFF the ratio display.)
----------	---

Structure	RST= ON/OFF
-----------	---

RST= : Setting command of the judgement reset.

ON/OFF	: Designate the reset of judgement output with "ON". Designate the cancellation of reset with "OFF".
--------	---

Transmission

Rest the comparator judgement output.

RST=ON

One sampling hold

While the 3566 is in hold status, and when the reset is made ON and afterward turned OFF, one sampling hold can be done.

4.2.22 RST? (read-out of judgement reset status)

Function	Read out the status of comparator judgement reset.
----------	--

Structure	RST?
-----------	------

Transmission

RST?

Response

RST=OFF

Shows the data output of reset.

Shows the status of reset. (data length = 3)

4.2.23 SAMPLING= (setting of sampling rate)

Function

Set the sampling rate.

Structure

SAMPLING= SLOW/MEDIUM/FAST

SAMPLING= : Setting command of the sampling rate.

SLOW/MEDIUM/FAST

:

50Hz

60Hz

SLOW : 1.56 times/sec. 1.88 times/sec.

MEDIUM : 6.25 times/sec. 7.52 times/sec.

FAST : 50 times/sec. 60 times/sec.

Transmission

Set the measuring sampling rate to low speed.

SAMPLING=SLOW

4.2.24 SAMPLING? (read-out of sampling rate)

Function

Read out the status of sampling rate.

Structure

SAMPLING?

Transmission

SAMPLING?

Response

SAMPLING=SLOW

Shows the sampling data output.
Shows the status. (data length = 6)

4.2.25 ZEROADJ= (setting of zero adjustment)

Function	Make the setting of zero adjustment. The zero adjustment action is that the measured value at the moment when the ZEROADJ=ON is received is memorized as the zero set value, and the value deducted the zero set value from the measured value is displayed and output until the ZEROADJ=OFF is received.
----------	--

Structure	ZEROADJ= ON/OFF ZEROADJ= : Zero adjustment setting command. ON/OFF : Designate the effect with “ON”. Designate the cancellation with “OFF”.
-----------	--

Transmission

Set the zero adjustment to ON.

ZEROADJ=ON

4.2.26 ZEROADJ? (read-out of zero adjustment)

Function	Read out the status of zero adjustment.
----------	---

Structure	ZEROADJ?
-----------	----------

Transmission

ZEROADJ?

Response

ZEROADJ=OFF

Shows the status of zero adjustment output.
Shows the status of zero adjustment. (data length = 3)

4.2.27 VIEW= (setting of display mode)

Function	Make the setting of display mode.
Structure	VIEW= Display mode Display mode= : Display mode setting command. Display mode : “OHM” Rr mode “VOLT” Vv mode “OHM-VOLT” RV mode
Transmission	Set the display mode to Rr. VIEW=“OHM”

4.2.28 VIEW? (read-out of display mode)

Function	Read out the display mode.
Structure	VIEW?
Transmission	VIEW?
Response	VIEW=OHM-VOLT

Shows the display mode. (data length = 8)

Instruction Manual
Interface of RS-485

MODEL 5811-06A
(for Model 3566)

I-01550

TSURUGA ELECTRIC CORPORATION

Contents

Page

1.Specifications	3
2.Connection	3
2.1 Connector terminals	3
2.2 Switch for device numbering	3
2.3 Terminator	3
2.4 Connection	4
3.Communication	4
3.1 Remote control	4
3.2 Explanation of communication	4
4.Data format	5
5.Explanation of command	6
5.1 Command data	6
5.2 Detail of command data	7
5.2.1 ONLINE= (setting of online)	7
5.2.2 ONLINE? (read-out of online)	7
5.2.3 BUZZ= (setting of buzzer)	8
5.2.4 BUZZ? (read-out of buzzer data)	8
5.2.5 MODE= (changeover of mode)	9
5.2.6 MODE? (read-out of mode)	9
5.2.7 MEM=CALL (call-up of memory)	9
5.2.8 MEM No? (read-out of memory setting data)	10
5.2.9 MEM= (setting of memory data)	11
5.2.10 COMPR=, COMPV= (setting of comparator)	12
5.2.11 COMPR?, COMPV? (read-out of comparator data)	12
5.2.12 DATA? (read-out of measurement data)	13
5.2.13 FUNCTION= (measuring function)	14
5.2.14 FUNC? (read-out of function data)	14
5.2.15 HOLD= (setting of hold)	15
5.2.16 HOLD? (read-out of hold status)	15
5.2.17 RANGE= (setting of measuring range)	16
5.2.18 RANGE? (read-out of measuring range)	16
5.2.19 RATIOSTD= (setting of standard ratio value)	17
5.2.20 RATIOSTD? (read-out of standard ratio value data)	17
5.2.21 RST= (judgement reset)	18
5.2.22 RST? (read-out of judgement reset status)	18
5.2.23 SAMPLING= (setting of sampling rate)	19
5.2.24 SAMPLING? (read-out of sampling rate)	19
5.2.25 ZEROADJ= (setting of zero adjustment)	20
5.2.26 ZEROADJ? (read-out of zero adjustment status)	20
5.2.27 VIEW= (setting of display mode)	21
5.2.28 VIEW? (read-out of display mode)	21

1. Specifications

Table 1.1 Specifications

Synchronization system	Start-stop synchronous system
Communication system	2 wire half duplex system
Transmission speed	9600bps
Data bit length	7 bit
Stop bit	1 bit
Error detection	Vertical parity: Even number parity BCC
Data	Compatible with JIS 8 unit code
Control character	STX (02H) start of text ETX (03H) end of text
Transmission procedure	No procedure
Numbers of connectable devices	Max. 32 devices including the higher level computer
Line length	Max. 500m
Device numbering	00~99, set for each device (not to duplicate) Set with the rear panel switch.
Terminator	Terminates with 200 ON/OFF changeover with the rear panel switch.


2. Connection

2.1 Connection terminals

Terminal number	1	2
Signal name	+ (A)	- (B)

2.2 Switch for device numbering

Make a setting with the rotary switch on the rear panel.




2.3 Terminator

When the switch on the rear panel is switched ON, the terminator resistor 200 is connected in parallel.



2.4 Connection

RS-485 allows a connection of up to 32 units including the higher level computer. For the device at both end of transmission channel, it is necessary to make a designation as end station. To designate the end station, set the terminator switch to ON side.



3. Communication

3.1 Remote control


When the tester is in ONLINE status by the key operation on the front panel, remote control and read out of the data by means of RS-485 are enabled.

Control functions in ONLINE are as follows.

Setting and read out of each setting parameter are possible.

Read-out of the working status and measurement data is possible.

3.2 Explanation of communication



Response frame:

When the effective setting command is received, the content of receipt is returned.

When the effective output command is received, the designated data is output.

When the ineffective command is received, "Command Error" is returned.

Example: In case of effective command: FUNCTION=OHM,

Response: FUNCTION=OHM

In case of ineffective command: FUNCTION=MACHIGAI,

Response: Command Error

4. Data format

Command frame

Device No.										
STX	1	0	R	A	N	G	E	?	ETX	BCC
02H	31H	30H	52H	41H	4EH	47H	45H	3DH	03H	60H
$\times 10^1 \times 10^0$										

Response frame

Device No.														
STX	1	0	R	A	N	G	E	=	3	0	H	M	ETX	BCC
02H	31H	30H	52H	41H	4EH	47H	45H	3DH	33H	4FH	48H	4DH	03H	19H
$\times 10^1 \times 10^0$														


BCC: BCC is defined as the calculated result of the exclusive logical addition from immediately after STX to ETX (including ETX).

5. Explanation of command

5.1 Command data

JIS punctuation code is used for the command data.

Example:



1. STX Start code
2. Device No.
3. Command Command to control 3566
4. ETX Finish code
5. BCC Error detection code

5.2 Detail of command data

5.2.1 ONLINE= (setting of online)

Function	The settings and to do or not to the control through RS-485 is set.
Structure	ONLINE= <input type="text" value="ON/OFF"/>
	<input type="text" value="ON/OFF"/> : The setting and control through RS-485 is possible with "ON". The setting and control through RS-485 is not possible with "OFF".
Note:	The setting is not possible when the ONLINE is made by the dip switch on the rear.

5.2.2 ONLINE? (read-out of online)

Function	The setting of online is read out.
Structure	ONLINE?
Transmission	
	ONLINE?
Response	
	ONLINE OFF

5.2.3 BUZZ= (setting of buzzer)

Function	Make the setting of buzzer for OFF, GO, HI, LO, HI LO, PASS, FAIL, GOOD and NG.
----------	---

Structure	BUZZ= OFF/GO/HI/LO/HILO/PASS/FAIL/GOOD/NG , Data
-----------	--

BUZZ= : Buzzer setting command

OFF/GO/HI/LO/HILO/PASS/FAIL/GOOD/NG :

“OFF” designates the buzzer OFF.

“GO” designates the buzzer at GO.

“HI” designates the buzzer at HI.

“LO” designates the buzzer at LO.

“HILO” designates the buzzer at HI or LO.

“PASS” designates the PASS buzzer.

“FAIL” designates the FAIL buzzer.

“GOOD” designates the buzzer at GO and PASS buzzer.

“NG” designates the buzzer at HI, LO or FAIL buzzer.

Note: Either one of the buzzer setting is possible.

Data	: Designates the buzzer sound volume. Sound volume can be set in 9 steps “01” ~ “10”. Note: When the setting is buzzer OFF, the designation for buzzer sound volume is disregarded.
------	--

Transmission

Set GO buzzer sound level to 3.

BUZZ=GO,03

BUZZ=OFF (When the setting is OFF, the sound level setting is disregarded.)

5.2.4 BUZZ? (read-out of buzzer data)

Function	The mode and the sound volume of buzzer are read out.
----------	---

Structure	BUZZ?
-----------	-------

Transmission

BUZZ?

Response

BUZZ=PASS,03

The buzzer working mode.

The buzzer sound volume. (data length = 2)

5.2.5 MODE= (changeover of mode)

Function	Changeover of memory mode, manual mode.
Structure	MODE=[Mode]
	MODE= : Mode changeover command
	[Mode] : “MEMORY” designates the memory mode. “MANUAL” designates the manual mode.
Transmission	
	Designate to the memory mode.
	MODE=MEMORY

5.2.6 MODE? (read-out of mode)

Function	Read out the memory mode, manual mode.
Structure	MODE?
Transmission	
	MODE?
Response	
	MODE=MANUAL

5.2.7 MEM=CALL (call-up of memory)

Function	The memory designated by the No. is called up. Note: Make the setting after changing to the memory mode.
Structure	MEM=CALL [No.]
	MEM= : Memory number setting command.
	[No.] : Designate the memory “01” ~ “30”.
Transmission	
	Designates to the memory No.01 and works afterwards as the memory No.01.
	MEM=CALL01
	Note: If it is not in the memory mode, “Not Control” is returned.

5.2.8 MEM [No.]? (read-out of memory setting data)

Function Read out the memory data designated by the No.

Structure MEM [No.]?

[No.] : Designate the memory "01" ~ "30".

Transmission

MEM01?

Response

MEM=01, OHM_ _ _ _ , OHM _ _ _ _ _ , 300mOHM, RH35.000_OHM, RL100.00_OHM
, 5V_ , VH+5.0000V, VL-2.0000V

Shows the memory number (data length = 2).

Shows the display mode (data length = 8).

OHM_ _ _ _ _ : Rr mode

VOLT_ _ _ _ : Vv mode

OHM_VOLT : RV mode

Shows the resistance measurement function (data length = 10).

OHM_ _ _ _ _ : Resistance measurement

OHM-RATIO_ : Ratio display

Shows the resistance measurement range (data length = 7).

Shows the HI data of resistance comparator (data length = 12).

Shows the LO data of resistance comparator (data length = 12).

Shows the voltage measurement range (data length = 3).

When the resistance range is set to AUTO, the voltage measurement also works in the auto-range.

The set value is output as response data.

Shows the HI data of voltage comparator. (data length = 10).

Shows the LO data of voltage comparator. (data length = 10).

5.2.9 MEM= (setting of memory data)

Function

Set the memory data.

Note: Make the setting after changing to the memory mode.

Structure

MEM= [No.] , [VIEW] , [FUNC] , [RANGE] , RH [HI SET] ,
RL [LO SET] , [VOLT] , VH [HI SET] , VL [LO SET]

MEM= : Data setting command of the memory.
[No.] : Designate the memory number "01" ~ "30".
[VIEW] : Display mode "OHM", "VOLT", "OHM-VOLT".
[FUNC] : Function table "OHM", "OHM-RATIO".
[RANGE] : Designates either one of the resistance range
"30mOHM", "300mOHM", "30OHM", "300OHM",
"3000OHM", "3kOHM".
RH [HI SET] : High limit value data of the resistance comparator.
(Adjustable range of numeral: 0~35000)
RL [LO SET] : Low limit value data of the resistance comparator.
(Adjustable range of numeral: 0~35000)
[VOLT] : Voltage range "5V", "50V".
VH [HI SET] : High limit value data of the voltage comparator.
(Adjustable range of numeral: ± 50000)
VL [LO SET] : Low limit value data of the voltage comparator.
(Adjustable range of numeral: ± 50000)

Note-1: RH [HI SET] and RL [LO SET] are to be set adding the unit and decimal point.

Example of setting: 35.000kOHM

Note-2: When the FUNC is RATIO, HI SET: Standard value,
LO SET: Deviation are to be set.

Example of setting: RH100.000OHM, RL10.0%

Note-3: VH [HI SET] and VL [LO SET] are to be set adding the unit and decimal point.

Example of setting: 45.000V

Note-4: Make the setting of memory in the memory mode.
(MODE=MEMORY)

Transmission

MEM=01, OHM, OHM, 300mOHM, RH35.0000HM, RL100.000HM, 5V, VH5.0000V, VL2.0000V

MEM=01, OHM, OHM-RATIO, 300OHM, RH15.0000HM, RL100.0%, 5V, VH5.0000V, VL2.0000V

Note: If it is not in the memory mode, "Not Control" is returned.

5.2.10 COMP=, COMPV= (setting of comparator)

Function	Set the high and low limit value and the unit of the comparator.	
Structure	COMP=RH[HI SET],RL[LO SET] COMP=VH[HI SET],VL[LO SET]	For resistance comparator For voltage comparator

COMP= : Comparator setting command

[HI SET] : High limit set value of the comparator
(Adjustable range of numeral 0~35000)

[LO SET] : Low limit set value of the comparator
(Adjustable range of numeral 0~35000)

Note-1: HI SET and LO SET are to be set adding the unit and decimal point.

Example of setting: 35.000kOHM, 5.0000V

Note-2: Adjust the unit and decimal point of HI SET and LO SET to the same.

Transmission

Set the HI SET of resistance comparator to 2.0000k and the LO SET to 1.5000k .
COMP=RH2.000kOHM,RL1.5000kOHM

Set the HI SET of voltage comparator to 15.000V and the LO SET to 2.000V.
COMPV=VH+15.000V,VL-02.000V

Note: In the memory mode, no setting is possible in the manual mode and the measuring function is RATIO (ratio display).

5.2.11 COMP=?, COMPV? (read-out of comparator data)

Function	Read out the high and low limit value, and unit of the comparator.	
Structure	COMP=? COMPV=?	Read-out of the resistance comparator Read-out of the voltage comparator

Transmission

COMP=?

Response

COMP=RH3.0000kOHM,RL1.0000kOHM

Shows the data output of resistance comparator.

Shows the HI data of the comparator (data length = 12).

Shows the LO data of the comparator (data length = 12).

Note: The read-out is not possible when the resistance measurement function is RATIO (ratio display).

Transmission

COMPV=?

Response

COMPV=VH+5.0000V,VL-1.0000V

Shows the data output of comparator.

Shows the HI data of the comparator. (data length = 10).

Shows the LO data of the comparator. (data length = 10).

5.2.12 DATA? (read-out of measurement data)

Function	Read out the measurement data.
----------	--------------------------------

Structure	DATA?
-----------	-------

DATA? : Measurement data output command

Transmission

DATA?

Response

1. Resistance measurement

OHM=+199.99kOHM,R-JUDGE=HI LO,VOLT=+0.1234V,V-JUDGE=FAIL

Resistance measurement data (data length = 11)

Resistance judgement output (data length = 13)

Voltage measurement data (data length = 13)

Voltage judgement output (data length = 12)

2. Ratio measurement

RATIO=+123.4%,Rs=1.0000_OHM,Rx=+1.2345_OHM,R-JUDGE=GO_____ ,

VOLT=+0.1234V,V-JUDGE=FAIL

Shows the ratio data (data length = 7)

Shows the resistance measurement data (data length = 13)

Shows the ratio standard resistance value (data length = 14)

Shows the resistance judgement output (data length = 13)

Shows the voltage measurement data (data length = 13)

Shows the voltage judgement output (data length = 12)

Note: R-JUDGE output

At GO : R-JUDGE=GO

At HI : R-JUDGE=HI

At LO : R-JUDGE=LO

At HI LO : R-JUDGE=HI LO

At No judgement output : R-JUDGE=NULL

At CC error : R-JUDGE=CC

(CC error means the SOURCE open.)

(At the CC error, the CC error is output regardless of the judgement result.)

V-JUDGE output

At good voltage judgement : V-JUDGE=PASS

At faulty voltage judgement : V-JUDGE=FAIL

At No judgement output : V-JUDGE=NULL

5.2.13 FUNCTION= (measuring function)

Function	Designate the measuring function.
Structure	FUNCTION= Function code FUNCTION= : Function setting command Function : “OHM” Resistance measurement, “OHM-RATIO” Ratio display.
Transmission	
Set the measuring function to the resistance measurement.	
FUNCTION=OHM FUNCTION=OHM-RATIO	

5.2.14 FUNC? (read-out of function data)

Function	Read out the measuring function.
Structure	FUNC? FUNC? : Measuring function output command
Transmission	
FUNC?	
Response	
FUNCTION=OHM_ _ _ _ _ FUNCTION=OHM-RATIO	

Shows the function data output. (data length = 9)
Shows the measuring function data.

5.2.15 HOLD= (setting of hold)

Function	Set the start and cancellation of the hold.
Structure	HOLD= ON/OFF
	HOLD= : Hold setting command.
	ON/OFF : Stop the sampling and hold the data with “ON”. Designate the cancellation of hold with “OFF”.
Transmission	
	Set the hold to ON.
	HOLD=ON

5.2.16 HOLD? (read-out of hold status)

Function	Read out the status of hold.
Structure	HOLD?
Transmission	
	HOLD?
Response	
	HOLD=ON_ HOLD=OFF
	Shows the hold data output.
	Shows the status data of the hold. (data length = 3)

5.2.17 RANGE= (setting of measuring range)

Function

Set the range of resistance measurement.

Note: No setting is possible in the temperature measurement.

Structure

RANGE=**Range**

RANGE= : Measuring range setting command

Range : For the resistance measurement, set the range among
30m ~ 3k .

To make the auto-range, set AUTO.

Table 5.1

Range code	Measuring range
30mOHM	30m
300mOHM	300m
30HM	3
300HM	30
3000HM	300
3kOHM	3k
AUTO	Auto-range

Transmission

Set the resistance measurement range to 30 .

RANGE=300HM

5.2.18 RANGE? (read-out of measuring range)

Function

Read out the setting condition of the measuring range.

Structure

RANGE?

Transmission

RANGE?

Response

RANGE=3__kOHM

Shows the range data output.

Shows the data of setting condition of the range. (data length = 7)

5.2.19 RATIOSTD= (setting of standard ratio value)

Function

Set the standard value and deviation of the ratio display.

Note: The setting is not possible when the measuring function is other than the ratio display function.

Structure

RATIOSTD=[REF], [±]

RATIOSTD : Setting command of the ratio standard value.

REF

 : Standard resistance value.

±

 : ± deviation data (00.0~199.9%)

Transmission

Set the 10.000 to the standard resistance value, and 20.0% to the deviation %.

RATIOSTD=10.000OHM,20.0%

Note: When the FUNCTION is not RATIO, “Not Control” is returned.

5.2.20 RATIOSTD? (read-out of standard ratio value)

Function

Read the data of ratio standard value.

Structure

RATIOSTD?

Transmission

RATIOSTD?

Response

RATIOSTD=10.000kOHM,020.0%

Shows the data output of the ratio standard.

Shows the data of standard value. (data length = 10)

Shows the deviation data %. (data length = 6)

5.2.21 RST= (judgement reset)

Function	Make ON/OFF of reset for the comparator judgement. (Reset the comparator output and turn OFF the ratio display.)
----------	---

Structure	RST= ON/OFF
-----------	---

RST= : Setting command of the judgement reset.

ON/OFF	: Designate the reset of judgement output with "ON". Designate the cancellation of reset with "OFF".
--------	---

Transmission

Rest the comparator judgement output.

RST=ON

One sampling hold

While the 3566 is in hold status, and when the reset is made ON and afterward turned OFF, one sampling hold can be done.

5.2.22 RST? (read-out of judgement reset status)

Function	Read out the status of comparator judgement reset.
----------	--

Structure	RST?
-----------	------

Transmission

RST?

Response

RST=OFF

Shows the data output of reset.

Shows the status of reset. (data length = 3)

5.2.23 SAMPLING= (setting of sampling rate)

Function Set the sampling rate.
The sampling rate for the temperature measurement is fixed at 4 times/sec. and no changeover is possible.

Structure SAMPLING= **SLOW/MEDIUM/FAST**

SAMPLING= : Setting command of the sampling rate.

SLOW/MEDIUM/FAST	:	50Hz	60Hz
SLOW	:	1.56 times/sec.	1.88 times/sec.
MEDIUM	:	6.25 times/sec.	7.52 times/sec.
FAST	:	50 times/sec.	60 times/sec.

Transmission

Set the measuring sampling rate to low speed (SLOW).

SAMPLING=SLOW

5.2.24 SAMPLING? (read-out of sampling rate)

Function Read out the status of sampling rate.

Structure SAMPLING?

Transmission

SAMPLING?

Response

SAMPLING=SLOW__

Shows the sampling data output.
Shows the status. (data length = 6)

Function	<p>Make the setting of zero adjustment.</p> <p>The zero adjustment action is that the measured value at the moment when the ZEROADJ=ON is received is memorized as the zero set value, and the value deducted the zero set value from the measured value is displayed and output until the ZEROADJ=OFF is received.</p>
Structure	<p>ZEROADJ=[ON/OFF]</p> <p>ZEROADJ= : Zero adjustment setting command.</p> <p>[ON/OFF] : Designate the effect with “ON”. Designate the cancellation with “OFF”.</p>
Transmission	<p>Set the zero adjustment to ON.</p> <p>ZEROADJ=ON</p>

5.2.26 ZEROADJ? (read-out of zero adjustment)

Function	Read out the status of zero adjustment.
Structure	ZEROADJ?
Transmission	
	ZEROADJ?
Response	
	ZEROADJ=OFF
	Shows the status of zero adjustment output.
	Shows the status of zero adjustment. (data length = 3)

5.2.27 VIEW= (setting of display mode)

Function	Make the setting of display mode.
Structure	VIEW= Display mode
	Display mode=: Display mode setting command.
Display mode	: "OHM" Rr mode "VOLT" Vv mode "OHM-VOLT" RV mode

Transmission

Set the display mode to Rr.

VIEW="OHM"

5.2.28 VIEW? (read-out of display mode)

Function	Read out the display mode.
----------	----------------------------

Structure	VIEW?
-----------	-------

Transmission

VIEW?

Response

VIEW=OHM-VOLT

Shows the display mode. (data length = 8)